

Miscellaneous

		44
		61
DOORS OPEN	DOORS CLOSE	90
CYCLE START	CYCLE STOP	91
SEMI AUTO	AUTO	92
		131
		132
		133
		149
		150
		159
HAND	AUTO	166
DOG HOUSE UP	DOG HOUSE DOWN	174
SUB DS UP	SUB DS DOWN	204
SUB ODS UP	SUB ODS DOWN	205
SUB CYL DS	SUB CYL ODS	209
SUB CYL BOTH		210
SUB CYL UP	SUB CYL DOWN	211

SUB CYL DS	SUB CYL ODS	209
SUB CYL BOTH		210
SUB CYL UP	SUB CYL DOWN	211
JACK ODS1 UP	JACK ODS1 DOWN	212
JACK ODS2 UP	JACK ODS2 DOWN	213
JACK ODS3 UP	JACK ODS3 DOWN	214
JACK DS1 UP	JACK DS1 DOWN	215
JACK DS2 UP	JACK DS2 DOWN	216
JACK DS3 UP	JACK DS3 DOWN	217
		221
SUB CYL CENTER	SUB CYL ALL	227
		234
ARTICULATE A EXTEND	ARTICULATE A RETRACT	261
ARTICULATE B EXTEND	ARTICULATE B RETRACT	262
SUB RAISE	SUB LOWER	263
ARTICULATE EXTEND	ARTICULATE RETRACT	264
BRACE EXTEND	BRACE RETRACT	265
PIN EXTEND	PIN RETRACT	266

		280
GUARD OPEN	GUARD CLOSED	298
DOORS 		299
DOG HOUSE RAISE	DOG HOUSE LOWER	301
ARTICULATE 1 EXTEND	ARTICULATE 1 RETRACT	305
ARTICULATE 2 EXTEND	ARTICULATE 2 RETRACT	306
AUTO STOP	BOTH	307
KICKER CYL EXTEND		310
FOG	JET	311
MON		312
YOKE CLOSE	YOKE OPEN	316
BACK BAR DOWN	BACK BAR UP	317
KICK DOORS CLOSE	KICK DOORS OPEN	318
BELLY BAND UP	BELLY BAND DOWN	319
BACK LEG UP	BACK LEG DOWN	320
TAKE CONTROL		351
GATE 1	GATE 2	352
GATE 3	GATE 4	353

Miscellaneous

GATE 5		GATE 6	354
GATE 7		GATE 8	355
GATE 9		GATE 10	356
GATE 11			357
			386
RDTL MAINTENANCE		RDTL TRANSPORT	396
PTO		AIR FREE SPOOL	407
CONVEYER OFF/ON			411
CONVEYER SWING LEFT		CONVEYER SWING RIGHT	412
CONVEYER EXTEND		CONVEYER RETRACT	413
POD LIFT		POD LOWER	414
U		L	415
DIVERTER			420
TOP 1 OPEN		TOP 1 CLOSE	451
TOP 2 OPEN		TOP 2 CLOSE	452
TORQUE		DE TORQUE	456
			460
ZERO 		AUTO 	461

REAR G/N HATBOX DOWN		REAR G/N HATBOX UP	462
JEEP LEVEL LEFT		JEEP LEVEL RIGHT	463
JEEP AXLES RETRACT		JEEP AXLES EXPAND	464
JEEP AXLES LEFT		JEEP AXLES RIGHT	465
LOAD		UNLOAD	474
SQUEEZE		RELEASE	475
SCREEN VERTICAL		SCREEN RADIAL	495
CLEAR FUNCTION		LMD1	497
CLEAR FUNCTION		LMD2	498
BASE STONE UP		BASE STONE DOWN	499
BASE STONE LEFT		BASE STONE RIGHT	500
RIP RAP UP		RIP RAP DOWN	501
RIP RAP LEFT		RIP RAP RIGHT	502
1/4" MINUS UP		1/4" MINUS DOWN	503
1/4" MINUS UP		1/4" MINUS DOWN	504
1/2" UP		1/2" DOWN	505
1/2" LEFT		1/2" RIGHT	506
3/4" UP		3/4" DOWN	507

3/4" LEFT		3/4" RIGHT	508
HAT BOX DOWN		HAT BOX UP	531
			534
			541
			542
		AUTO 	543
RADIAL CW		RADIAL CCW	548
LEFT FD EXTEND		LEFT FD RETRACT	549
RIGHT FD EXTEND		RIGHT FD RETRACT	550
AIR IN		AIR DUMP	568
BIN #1		BIN #2	575
BIN #3		BIN #4	576
BELT START		VIBRATOR START	578
BELT STOP		VIBRATOR STOP	579
TOP CLAMP		TOP RELEASE	588
CENTRE CLAMP		CENTRE RELEASE	589
LOWER CLAMP		LOWER RELEASE	590
OPEN 		CLOSE 	591

Miscellaneous

		592
		595
		596
		597
		598
		599
RELEASE	SQUEEZE	600
		611
FD UP	FD DOWN	612
RD UP	RD DOWN	613
MDF UP	MDF DOWN	614
MDR UP	MDR DOWN	615
A LOCK L	A LOCK R	616
INNER IN	INNER OUT	635
OUTER IN	OUTER OUT	636
		637
		638
		639

		640
		641
FRONT G/N TOWER LIFT RAISE	FRONT G/N TOWER LIFT LOWER	648
FRONT G/N TOWER TILT RAISE	FRONT G/N TOWER TILT LOWER	649
FRONT G/N SUPPORT RAISE	FRONT G/N SUPPORT LOWER	650
REAR G/N TOWER LIFT RAISE	REAR G/N TOWER LIFT LOWER	651
REAR G/N TOWER TILT RAISE	REAR G/N TOWER TILT LOWER	652
REAR G/N SUPPORT RAISE	REAR G/N SUPPORT LOWER	653
APPROACH DOWN	APPROACH UP	656
		663
		664
		665
		666
		667
		668
		669
		670
		671

		672
LOAD	UNLOAD	673
SHEET OPEN	SHEET CLOSED	675
SWEEP		676
UNDER BAR UP	UNDER BAR DOWN	677
Dead man	Dead man	685
		687
		688
BIN 1 OPEN	BIN 1 CLOSE	692
BIN 2 OPEN	BIN 2 CLOSE	693
BIN 3 OPEN	BIN 3 CLOSE	694
CONV. LIFT	CONV. LOWER	695
BRAKE	OPEN GATEVALVE CLOSE	698
		709
SCOPE IN	SCOPE OUT	710
PIVOT LEFT	PIVOT RIGHT	713
SOLAR 1 UP	SOLAR 1 DOWN	714
SOLAR 2 UP	SOLAR 2 DOWN	715

Miscellaneous

↑ S1		↓ S1	729
↑ S2		↓ S2	730
↑ S3		↓ S3	731
↑ V1		↓ V1	732
↑ V2		↓ V2	733
RADIO LATCH 1		RADIO LATCH 2	742
PUSH PUSH LATCH		PUSH PUSH LATCH	743
MULTI OUT 1		MULTI OUT 2	744
SCREEN ON		SCREEN OFF	754
		LMD	755
ARCH ROTATE 5		AUTO/ MANUAL 6	792
		POWER PACK	823
		RELEASE FRONT BRAKES	824
VAC BREAKER OPEN		VAC BREAKER CLOSE	835
DRIBBLE BAR OPEN		DRIBBLE BAR CLOSE	841
MACERATOR ON		MACERATOR OFF	842
CHANGE OVER SPREAD		CHANGE OVER FILL	843
SPREAD PLATE OPEN		SPREAD PLATE CLOSE	844

FRONT VALVE OPEN		FRONT VALVE CLOSE	848
		RAPID	855
NEW OPEN VAC BREAKER		NEW CLOSE VAC BREAKER	859
CAMERA 1		CAMERA 2	865
CAMERA 3		CAMERA 4	866
ON LEFT FRONT ROLLERS		OFF LEFT FRONT ROLLERS	869
ON LEFT REAR ROLLERS		OFF LEFT REAR ROLLERS	870
ON RIGHT FRONT ROLLERS		OFF RIGHT FRONT ROLLERS	871
ON RIGHT REAR ROLLERS		OFF RIGHT REAR ROLLERS	872
VAC ON		VAC OFF	967
S2		OUT	1008
		IN	1019
W		B	1020
W		B	1021
Main Lock		Main Open	1030
Full Bank		Part Bank	1031
Main Blowdown		S.B.F. Blowdown	1032
S.B.F. Charge		Main Charge	1033

S.B.F. Lock		S.B.F. Open	1034
Charge Pump On		Charge Pump Off	1035
SBF Glycol Charge		SBF Glycol Drain	1036
Main Glycol Charge		Main Glycol Drain	1037
THROTTLE UP/DOWN		BALE/LOG	1057
E-STOP		AUTO CYCLE	1058
LEFT LID CLOSE		LEFT LID OPEN	1059
RIGHT LID CLOSE		RIGHT LID OPEN	1060
RAM OUT		RAM IN	1061
CLUTCH ON / OFF		CHOKE ON / OFF	1075
CHOKER OPEN		CHOKER CLOSE	1076
CONVEYOR 1 ON / OFF		FAST SLOW	1077
		BREAKER VAC	1083
Kick UP		Kick DOWN	1089
Neck Tilt UP		Neck Tilt DOWN	1093
FOLD UP		FOLD DOWN	1096
Inlet Valve OFF		Inlet Valve ON	1100
Jaws UP		Jaws DOWN	1103

Miscellaneous

			1104
Post UP		Post DOWN	1117
CLAWS OPEN		CLAWS CLOSE	1120
Belt Motor ON/OFF		Belt ON/OFF	1122
Reel IN		Reel OUT	1126
		Fast Offload	1141
			1149
			1150
			1151
O/S		N/S	1172
RAIL GEAR WORK LIGHTS		RAIL GEAR ACTIVATE	1174
Choke ENGAGE		Choke DISENGAGE	1177
Dump Valve ENGAGE/ DISENGAGE			1178
Yoke CLOSE		Yoke OPEN	1182
Doors CLOSED		Doors OPEN	1183
Main Valve OPEN		Main Valve CLOSE	1188
Small Valve OPEN		Small Valve CLOSE	1189
Air Bags UP		Air Bags DOWN	1190

Air Blast		Override	1191
Landing UP		Landing DOWN	1192
Tank OPEN		Tank CLOSE	1193
Main Pump OPEN		Main Pump CLOSE	1194
Ball Chute OPEN		Ball Chute CLOSE	1195
			1196
			1197
DOORS CLOSE 1		DOORS OPEN 1	1205
DOORS CLOSE 2		DOORS OPEN 2	1206
Ejector Ram IN		Ejector Ram OUT	1228
Cover Roll ON		Cover Roll OFF	1229
Cover Roll OFF		Cover Roll ON	1230
Ejector Ram OUT		Ejector Ram IN	1232
			1233
Vibration EIN		Vibration AUS	1240
Frequenz ▲		Frequenz ▼	1241
Vibration EIN/AUS		Drehrichtung RECHTS/LINKS	1242
Rüttlung EIN-AUS		Nach-Rütteln EIN-AUS	1254

Rüttlung Frequenz ▲		Nach-Rütteln Frequenz ▲	1255
Rüttlung Frequenz ▼		Nach-Rütteln Frequenz ▼	1256
BAG UP		BAG DOWN	1264
BAG IN		BAG OUT	1265
PAN UP		PAN DOWN	1266
Eject UP		Eject DOWN	1267
FREEWHEEL		SPARE	1269
Swing Jack DOWN		Swing Jack UP	1271
JIG 2 IN		JIG 2 OUT	1276
JIG 1 IN		JIG 1 OUT	1277
MAN ON		MAN OFF	1278
Seat UP ▲		Seat DOWN ▼	1286
Start Wickeln		Stop Wickeln	1289
TUB FORWARD		TUB REVERSE	1290
Yoke IN		Yoke OUT	1291
Door OPEN		Door SHUT	1292
Squeeze IN		Squeeze OUT	1293
Back Bar IN		Back Bar OUT	1294

Miscellaneous

Aus	Ein	1312
PRESSURE RELEASE		1315
VIBRATOR STOP	VIBRATOR START	1319
F Nozzle UP	F Nozzle DOWN	1321
F Nozzle LEFT	F Nozzle RIGHT	1322
R Nozzle UP	R Nozzle DOWN	1323
R Nozzle LEFT	R Nozzle RIGHT	1324
R Valve OPEN	R Valve CLOSE	1325
Shift LEFT	Shift RIGHT	1328
D2 Front 	D2 Front 	1332
D2 Fwd	D2 Back	1333
D2 Rear 	D2 Rear 	1334
D3 Front 	D3 Front 	1335
D3 Fwd	D3 Back	1336
D3 Rear 	D3 Rear 	1337
		1339
		1340
		1341

		1342
		1343
		1344
		1345
 GARAGE OPEN	 GARAGE CLOSE	1347
LH Door OPEN	LH Door CLOSE	1351
RH Door OPEN	RH Door CLOSE	1352
BUCKET UP	BUCKET DOWN	1354
		1356
Hold Air	Air In	1357
		1358
		1359
		1360
Blade IN	Blade OUT	1364
EJECT UP	EJECT DOWN	1384
CLAMP	UN-CLAMP	1385
		1386
RELEASE 	SQUEEZE 	1387

Float	Lock	1389
Centre		1391
Tower 1 RAISE	Tower 1 LOWER	1392
Tower 2 RAISE	Tower 2 LOWER	1393
Grapple UP	Grapple DOWN	1400
EJECT UP	EJECT DOWN	1401
CLAMP	UN-CLAMP	1402
BLADE 1 UP	BLADE 1 DOWN	1416
BLADE 2 UP	BLADE 2 DOWN	1417
BLADE 3 UP	BLADE 3 DOWN	1418
BLADE 4 UP	BLADE 4 DOWN	1419
LEFT GATE OPEN	LEFT GATE CLOSED	1420
RIGHT GATE OPEN	RIGHT GATE CLOSED	1421
LEFT PAD DOWN	LEFT PAD UP	1422
RIGHT PAD DOWN	RIGHT PAD UP	1423
Side OPEN	Side SQUEEZE	1424
Roll DOWN	Roll OVER	1425
Sand Fwd	Sand Rev	1426

Miscellaneous

4-10 Fwd	4-10 Rev	1427
Raise Grill	Lower Grill	1428
VACUUM  AIR		1431
		1432
		1433
Gate 1 OPEN	Gate 1 CLOSED	1434
Gate 2 OPEN	Gate 2 CLOSED	1435
		1437
Vac Pump ON/OFF		1441
Inlet Valve CLOSED	Inlet Valve OPEN	1442
Varsi Nosto	Varsi Lasku	1444
Kääntö Vasen	Kääntö Oikea	1445
Kääntö Nopeus +	Kääntö Nopeus -	1446
Lukitus Päälle	Lukitus Pois	1447
Jyrsin Päälle	Jyrsin Pois	1448
Yoke ↓	Yoke ↑	1449
Chute ←	Chute →	1450
Deflector ↓	Deflector ↑	1451

Loader START	Loader STOP	1458
Vibrator START		1459
CW	ACW	1460
SCR ON/OFF	SP-1	1461
Reset	LMD	1462
Lift Right Side	Let Down Right Side	1463
Lift Left Side	Let Down Left Side	1464
GRIP	UNGRIIP	1475
PITCH DOWN	PITCH UP	1476
WINDOW OPEN	WINDOW CLOSE	1482
CABLE UP	CABLE DOWN	1483
GARAGE OPEN	GARAGE CLOSE	1484
Intake UP	Intake DOWN	1490
Discharge UP	Discharge DOWN	1491
		1494
Pay OUT	Pay IN	1500
		1502
		1503

		1504
		1505
Sheet OPEN	Sheet CLOSE	1508
Sweep IN	Flaps UP	1509
Spray		1510
DOOR 1 OPEN	DOOR 1 CLOSE	1517
DOOR 2 OPEN	DOOR 2 CLOSE	1518
		1525
VIB. ON	VIB. OFF	1528
GLOW PLUGS		1544
F FEED IN	F FEED OUT	1551
KITCH IN	KITCH OUT	1552
LIVING IN	LIVING OUT	1553
R FEED IN	R FEED OUT	1554
OUT F FEED	IN F FEED	1555
OUT BATH	IN BATH	1556
OUT KITCH	IN KITCH	1557
OUT LIVING	IN LIVING	1558
OUT R	IN R	

Miscellaneous

		1559
D5	D1	1570
D7	D6	1571
	D8	1572
	R1	1573
		1574
PORTE POGO	PORTE ENTREPOT	1575
		1579
OPEN	OPEN	1594
CLOSE	CLOSE	1595
DUMP	DUMP	1596
SET	SET	1597
NOSTO	LASKU	1606
KÄÄNTÖ	KÄÄNTÖ	1607
TAITTO	TAITTO	1608
VEITSI	VEITSI	1609
PUMPPU ON	PUMPPU OFF	1610
TARP OPEN	TARP CLOSED	1611

		1616
		1617
		1618
		1619
		1621
		1622
		1623
		1624
		1625
	DEADMAN SWITCH	1626
		1627
SLEW BACK	SLEW FORWARD	1631
SCREEN DOWN	SCREEN UP	1635
SCREEN FOLD	SCREEN UNFOLD	1636
SCREEN ANTI CLOCK	SCREEN CLOCK WISE	1637
SPEAK IN	SPEAK OUT	1638
BANNER IN	BANNER OUT	1639
TOP BANNER DOWN	TOP BANNER UP	1640

FILLER START	FILLER STOP	1642
JAR STOP IN	JAR STOP OUT	1643
DIVERT & INDIVERT	BROKEN JAR	1644
MAIN LIFT UP	MAIN LIFT DOWN	1646
FOLD UP	FOLD DOWN	1647
STABILIZER UP	STABILIZER DOWN	1651
	JETTER	1653
	BREAKER VAC	1654
MULE IN	MULE OUT	1660
SLIDE 1 IN	SLIDE 1 OUT	1661
SLIDE 2 IN	SLIDE 2 OUT	1662
LEFT DOLLY DOWN	LEFT DOLLY UP	1663
RIGHT DOLLY DOWN	RIGHT DOLLY UP	1664
DOLLY LEFT	DOLLY RIGHT	1665
TAIL SHIFT LEFT	TAIL SHIFT RIGHT	1666
		1668
VACUUM	RECIRC	1681
HOFF 1 OIL 1	HOFF 1 OIL 2	1682

Miscellaneous

HOFF 2 OIL 1	HOFF 2 OIL 2	1683
		1693
		1694
T	N	1698
RAISE FLOOR 	LOWER FLOOR 	1707
TROLLEY EAST	TROLLEY WEST	1709
SPOUT DEFLECTOR FWD	SPOUT DEFLECTOR REV	1720
SPOUT LEFT	SPOUT RIGHT	1721
LIFT	DOWN PRESSURE	1722
FEED ROLLER FWD	FEED ROLLER REV	1723
SIDE UP	SIDE DOWN	1730
JUMP	JETTER	1732
OUT REEL	IN REEL	1733
REEL OUT	REEL IN	1736
PRESSURE	VACUUM	1737
STAGING DOORS CLOSE	STAGING DOORS OPEN	1745
PUSH BAR DOWN	PUSH BAR UP	1746
HEAD GATE CLOSE	HEAD GATE OPEN	1747

CAGE UP	CAGE DOWN	1749
LEG LATCH RELEASE	COW RELEASE	1754
SIDE UP	SIDE DOWN	1759
SHEET SYSTEM RAISE	SHEET SYSTEM LOWER	1760
SHEET SYSTEM EXT-RAISE	SHEET SYSTEM EXT-LOWER	1761
SLIDE BARS OUT	SLIDE BARS IN	1762
 Fold Up	 Fold Down	1766
 DER Up	 DER Down	1767
 EX Out	 EX In	1768
 N/S FLAP DOWN	 N/S FLAP UP	1775
 O/S FLAP DOWN	 O/S FLAP UP	1776
 CAB DEFLECTOR UP	 CAB DEFLECTOR DOWN	1777
		1779
		1780
		1781
		1782
		1783
TOP BOX 	TOP BOX 	1784

TOP SKIN 	TOP SKIN 	1785
		1789
		1802
		1814
		1815
LOWER DOWN	LOWER UP	1819
LOWER IN	LOWER OUT	1820
DEADMAN SWITCH	DEADMAN SWITCH	1827
		1828
		1836
		1837
		1842
		1844
		1845
		1846
		1847
ALIGNMENT	PRESSURE	1848
HIGH PRESSURE	LOW PRESSURE	1849

Miscellaneous



RIGHT SIDE UP		RIGHT SIDE DOWN	1856
LEFT SIDE UP		LEFT SIDE DOWN	1857
			1867
			1872
			1873