

		1			17			36
		18R			18			37
		2			19			38
		3			20			39
		4			21			40
		5			22			41
		5R			23			42
		6			24			43
		6R			25			44
		7			26			45
		8			27			46
		9			28			47
		10			29			48
		11			30			49
		12			31			50
		13			32			51
		14			33			52
		15			34			53
		16			35			54

		55			74			93
		56			75			94
		57			76			95
		58			77			96
		59			78			97
		60			79			98
		61			80			99
		62			81			100
		63			82			101
		64			83			102
		65			84			103
		66			85			104
		67			86			105
		68			87			106
		69			88			107
		70			89			108
		71			90			109
		72			91			110
		73			92			111

#1429 is similar













		112			131			150
		113			132	GEN START	GEN STOP	151
		114			133	FEED MAX	SPREAD MAX	152
		115			134	FEED 4	SPREAD 4	153
		116			135	FEED 3	SPREAD 3	154
		117			136	FEED 2	SPREAD 2	155
		118			137	FEED MIN	SPREAD MIN	156
		119			138			157
		120			139			158
		121			140			159
		122			141			160
		123			142			161
		124	BEACON ON	BEACON OFF	143			162
		125	STROBE ON	STROBE OFF	144			163
		126	WORK LIGHTS ON	WORK LIGHTS OFF	145			164
		127			146			165
		128			147	HAND	AUTO	166
		129			148	SUB UP	SUB DOWN	167
		130			149	D.S. FRONT UP	D.S. FRONT DOWN	168

O.D.S. FRONT UP	O.D.S. FRONT DOWN	169			188	MAST TELE UP	MAST TELE DOWN	207
O.D.S. REAR UP	O.D.S. REAR DOWN	170			189	LOCK PIN IN	LOCK PIN OUT	208
D.S. MAST	O.D.S. MAST	171			190	SUB CYL DS	SUB CYL ODS	209
BOTH MAST		172			191	SUB CYL BOTH		210
MAST UP	MAST DOWN	173			192	SUB CYL UP	SUB CYL DOWN	211
DOG HOUSE UP	DOG HOUSE DOWN	174			193	JACK ODS1 UP	JACK ODS1 DOWN	212
WINCH UP	WINCH DOWN	175			194	JACK ODS2 UP	JACK ODS2 DOWN	213
D.S. SUB WINCH	O.D.S. SUB WINCH	176			195	JACK ODS3 UP	JACK ODS3 DOWN	214
BOTH SUB WINCH		177			196	JACK DS1 UP	JACK DS1 DOWN	215
SUB WINCH UP	SUB WINCH DOWN	178			197	JACK DS2 UP	JACK DS2 DOWN	216
RIG WINCH1 UP	RIG WINCH1 DOWN	179			198	JACK DS3 UP	JACK DS3 DOWN	217
RIG WINCH2 UP	RIG WINCH2 DOWN	180			199			218
D.S. REAR UP	D.S. REAR DOWN	181			200			219
WINCH IN	WINCH OUT	182			201	LOCK 3	UNLOCK 3	220
FRONT UP	FRONT DOWN	183			202			221
REAR UP	REAR DOWN	184			203	ENGINE START	ENGINE STOP	222
FRONT LOCKS	REAR LOCKS	185	SUB DS UP	SUB DS DOWN	204			223
 BLOWER	 AUX	186	SUB ODS UP	SUB ODS DOWN	205			224
START	STOP	187	MAST RAISE	MAST LOWER	206			225

RPM RPM RPM		226			245	ARTICULATE EXTEND	ARTICULATE RETRACT	264
SUB CYL CENTER	SUB CYL ALL	227			246	BRACE EXTEND	BRACE RETRACT	265
FOLD IN	FOLD OUT	228			247	PIN EXTEND	PIN RETRACT	266
BOW THRUST 	BOW THRUST 	229			248			267
 DRIVE	DRIVE 	230	LOCK OUT		249			268
STERN THRUST 	STERN THRUST 	231			250			269
PUMP RUN		232			251			270
PUMP RAISE	PUMP LOWER	233			252			271
		234			253			272
WINCH R1	WINCH F1	235			254			273
WINCH R2	WINCH F2	236	HAND	AUTO	255			274
WINCH R3	WINCH F3	237	MAST RAISE	MAST LOWER	256			275
WINCH R4	WINCH F4	238	STOP	BOTH	257			276
WINCH R5	WINCH F5	239	DS MAST RAISE	DS MAST LOWER	258			277
BOOM  LIGHTS	WORK  LIGHTS	240	ODS MAST RAISE	ODS MAST LOWER	259			278
WINGS  	WINGS  	241	DRILLERS SIDE	OFF DRILLERS SIDE	260			279
 DECK	 DECK	242	ARTICULATE A EXTEND	ARTICULATE A RETRACT	261			280
RAMP 	RAMP 	243	ARTICULATE B EXTEND	ARTICULATE B RETRACT	262			281
		244	SUB RAISE	SUB LOWER	263			282

FAST		SLOW	283	KICKER CYL EXTEND		SPARE	302			DRIVE	321
 LEGS		 LEGS	284	AUX 5		AUX 6	303			DOWN	322
			285				304	BRAKE		ENGINE START	323
			286	ARTICULATE 1 EXTEND		ARTICULATE 1 RETRACT	305				324
			287	ARTICULATE 2 EXTEND		ARTICULATE 2 RETRACT	306	BOTTOM		TOP	325
			288	AUTO STOP		BOTH	307				326
			289	DRILL FLOOR RAISE		DRILL FLOOR LOWER	308				327
 LIGHTS		 AUX	290	AUTO DRILL FLOOR RAISE		AUTO DRILL FLOOR LOWER	309				328
			291	KICKER CYL EXTEND			310	1 15		2 16	329
			292	FOG		JET	311	3 17		4 18	330
			293	MON			312	5 19		6 20	331
			294	START STOP		LIGHTS ON/OFF	313	7 21		8 22	332
			295				314	9 23		10 24	333
			296				315	11 25		12 26	334
			297	YOKE CLOSE		YOKE OPEN	316	13 27		14 28	335
GUARD OPEN		GUARD CLOSED	298	BACK BAR DOWN		BACK BAR UP	317	SHIFT		SHIFT LOCK	336
DOORS 			299	KICK DOORS CLOSE		KICK DOORS OPEN	318	1 13		2 14	337
AUTO MAST RAISE		AUTO MAST LOWER	300	BELLY BAND UP		BELLY BAND DOWN	319	OPEN		CLOSE	338
DOG HOUSE RAISE		DOG HOUSE LOWER	301	BACK LEG UP		BACK LEG DOWN	320				339

		340			359			378
		341			360			379
		342			361			380
		343			362			381
		344			363			382
		345			364			383
		346			365			384
		347			366			385
		348			367			386
		349			368			387
		350			369			388
		351			370			389
		352			371			390
		353			372			391
		354			373			392
		355			374			393
		356			375			394
		357			376			395
		358			377			396

		397			416			431
		398			417			432
		399			418			433
		400			418			434
		401			419			435
		402			419			436
		403			420			437
		404			421			438
		405			422			439
		406			422			440
PTO	AIR FREE SPOOL	407			423			441
BEACON	FLASH	408			424			442
WORK LIGHT 1	WORK LIGHT 2	409			425			443
		410			426			444
CONVEYER OFF/ON		411			3??			445
CONVEYER SWING LEFT	CONVEYER SWING RIGHT	412			427			446
CONVEYER EXTEND	CONVEYER RETRACT	413			428			447
POD LIFT	POD LOWER	414			429			448
U	L	415			430	17	18	449

19	20	450	OPEN	CLOSED	468			487
TOP 1 OPEN	TOP 1 CLOSE	451	RIGHT	LEFT	469			488
TOP 2 OPEN	TOP 2 CLOSE	452	RPM UP	RPM DOWN	470			489
BRAKES	AUX 1	452	RPM SET 1	RPM SET 2	471	CANOPY OPEN	CANOPY CLOSE	490
AUX 2	AUX 3	453	WATER PUMP ON	WATER PUMP OFF	472		REVERSE	491
		454	AUX 1	AUX 2	473			492
EXTEND	RETRACT	455	LOAD	UNLOAD	474	LEG A	LEG B	493
TORQUE	DE TORQUE	456	SQUEEZE	RELEASE	475	LEG D	LEG C	494
TAILSTOCK EXTEND	TAILSTOCK RETRACT	457	EXTEND	RETRACT	476	SCREEN VERTICAL	SCREEN RADIAL	495
PUMP 		458	FLOAT	LIGHT	477	UP CW	DOWN ACW	496
		459	Boom UP	Boom DOWN	478	CLEAR FUNCTION	LMD1	497
		460	Boom IN	Boom OUT	479	CLEAR FUNCTION	LMD2	498
ZERO 	AUTO 	461	Boom OPEN	Boom CLOSED	480	BASE STONE UP	BASE STONE DOWN	499
REAR G/N HATBOX DOWN	REAR G/N HATBOX UP	462	Boom LEFT	Boom RIGHT	481	BASE STONE LEFT	BASE STONE RIGHT	500
JEEP LEVEL LEFT	JEEP LEVEL RIGHT	463	RPM UP	RPM DOWN	482	RIP RAP UP	RIP RAP DOWN	501
JEEP AXLES RETRACT	JEEP AXLES EXPAND	464	RPM SET 1	RPM SET 2	483	RIP RAP LEFT	RIP RAP RIGHT	502
JEEP AXLES LEFT	JEEP AXLES RIGHT	465	WATER 	VACUUM 	484	1/4" MINUS UP	1/4" MINUS DOWN	503
UP	DOWN	466	AUX 1	AUX 2	485	1/4" MINUS UP	1/4" MINUS DOWN	504
IN	OUT	467			486	1/2" UP	1/2" DOWN	505

1/2" LEFT	1/2" RIGHT	506			525			544
3/4" UP	3/4" DOWN	507			526			545
3/4" LEFT	3/4" RIGHT	508			527			546
BED IN	BED OUT	509			528			547
BED UP	BED DOWN	510	FRONT AXLES RETRACT	FRONT AXLES EXPAND	529	RADIAL CW	RADIAL CCW	548
WINCH IN	WINCH OUT	511	FRONT AXLES LEFT	FRONT AXLES RIGHT	530	LEFT FD EXTEND	LEFT FD RETRACT	549
WHEEL LIFT UP	WHEEL LIFT DOWN	512	HAT BOX DOWN	HAT BOX UP	531	RIGHT FD EXTEND	RIGHT FD RETRACT	550
WHEEL LIFT IN	WHEEL LIFT OUT	513	REAR AXLES RETRACT	REAR AXLES EXPAND	532	INCLINE EXTEND	INCLINE RETRACT	551
JAWS OPEN	JAWS CLOSED	514	REAR AXLES LEFT	REAR AXLES RIGHT	533	STINGER EXTEND	STINGER RETRACT	552
FOLD	UNFOLD	515			534	STINGER BELT	MAIN BELT	553
EXTEND	RETRACT	516			535	HORN	HYD. MOTOR	554
BOOM UP	BOOM DOWN	517			536			555
BOOM IN	BOOM OUT	518			537			556
		519			538			557
		520			539			558
		521			540			559
		522			541			560
		523			542			561
		524		AUTO	543			562

		563	ALL UP	ALL DOWN	582			601
		564	FRONT UP	FRONT DOWN	583	WATER ON	WATER OFF	602
		565	REAR UP	REAR DOWN	584			603
		566	RIGHT WINCH IN	RIGHT WINCH OUT	585			604
		567	LEFT WINCH IN	LEFT WINCH OUT	586			605
AIR IN	AIR DUMP	568	RAISE	LOWER	587			606
		569	TOP CLAMP	TOP RELEASE	588			607
		570	CENTRE CLAMP	CENTRE RELEASE	589			608
		571	LOWER CLAMP	LOWER RELEASE	590			609
		572	OPEN	CLOSE	591			610
AUX 1	AUX 2	573	OPEN	CLOSE	592			611
		574			593	FD UP	FD DOWN	612
BIN #1	BIN #2	575			594	RD UP	RD DOWN	613
BIN #3	BIN #4	576	EXTEND SWEEP	RETRACT SWEEP	595	MDF UP	MDF DOWN	614
LEFT	RIGHT	577			596	MDR UP	MDR DOWN	615
BELT START	VIBRATOR START	578			597	A LOCK L	A LOCK R	616
BELT STOP	VIBRATOR STOP	579			598	ROOF UP	ROOF DOWN	617
		580			599	BD UP	BD DOWN	618
		581	RELEASE	SQUEEZE	600	SWING IN	SWING OUT	619

Reel IN		Reel OUT	620				639	AXLES BACK		AXLES FORWARD	657
			621				640	RAMP DOWN		RAMP UP	658
			622				641	TAIL EXT UP		TAIL EXT DOWN	659
			623	RAMP DOWN		RAMP UP	642	TAIL EXT LOCK		TAIL EXT UNLOCK	660
			624	AXLES BACK		AXLES FWD	643	DOVE TAIL DOWN		DOVE TAIL UP	661
			625	TOP WINCH IN		TOP WINCH OUT	644	DOVE TAIL LOCK		DOVE TAIL UNLOCK	662
			626	LOWER WINCH IN		LOWER WINCH OUT	645				663
			627	RAMP DOWN		RAMP UP	646				664
			628	AXLES BACK		AXLES FORWARD	647				665
			629	FRONT G/N TOWER LIFT RAISE		FRONT G/N TOWER LIFT LOWER	648				666
			630	FRONT G/N TOWER TILT RAISE		FRONT G/N TOWER TILT LOWER	649				667
			631	FRONT G/N SUPPORT RAISE		FRONT G/N SUPPORT LOWER	650				668
			632	REAR G/N TOWER LIFT RAISE		REAR G/N TOWER LIFT LOWER	651				669
			633	REAR G/N TOWER TILT RAISE		REAR G/N TOWER TILT LOWER	652				670
TILT UP		TILT DOWN	634	REAR G/N SUPPORT RAISE		REAR G/N SUPPORT LOWER	653				671
INNER IN		INNER OUT	635	WINCH IN		WINCH OUT	654				672
OUTER IN		OUTER OUT	636	RAMP DOWN		RAMP UP	655	LOAD		UNLOAD	673
			637	APPROACH DOWN		APPROACH UP	656	TAIL GATE UP		TAIL GATE DOWN	674
			638					SHEET OPEN		SHEET CLOSED	675

SWEEP			676	CONV. LIFT		CONV. LOWER	695	SOLAR 1 UP		SOLAR 1 DOWN	714
UNDER BAR UP		UNDER BAR DOWN	677	RAISE		LOWER	696	SOLAR 2 UP		SOLAR 2 DOWN	715
ALL DEC		ALL INC	678	EXTEND		RETRACT	697	AUX 1		AUX 2	716
D1 DEC		D1 INC	679	BRAKE		OPEN GATEVALVE CLOSE	698	AUX 3		AUX 4	717
D2 DEC		D2 INC	680				699				718
D3 DEC		D3 INC	681				700				719
D1		D1 	682				701				720
D2		D2 	683	BLOWER ON		BLOWER OFF	702				721
D3		D3 	684				703	DRAIN OPEN 		DRAIN CLOSED 	722
Dead man		Dead man	685				704	JETTER ON/OFF			723
			686				705	THROTTLE UP		THROTTLE DOWN	724
			687				706	MID AXLES RETRACT		MID AXLES EXPAND	725
			688				707	MID AXLES LEFT		MID AXLES RIGHT	726
			689				708	DISCHARGE VERTICAL LIGHT			727
			690				709	JACKS UP		JACKS DOWN	728
CONV. 		PUMP 	691	SCOPE IN		SCOPE OUT	710				729
BIN 1 OPEN		BIN 1 CLOSE	692	MAST TILT UP		MAST TILT DOWN	711				730
BIN 2 OPEN		BIN 2 CLOSE	693	MAST FOLD UP		MAST FOLD DOWN	712				731
BIN 3 OPEN		BIN 3 CLOSE	694	PIVOT LEFT		PIVOT RIGHT	713				732

		733	HYD ON	HYD OFF	752	Jib Rotate Left	Jib Rotate Right	771
		734	CLOCKWISE	ANTI-CLOCKWISE	753	Telescopic Boom In	Telescopic Boom Out	772
		735	SCREEN ON	SCREEN OFF	754	Turret Rotate Left	Turret Rotate Right	773
		736		LMD	755	Translation Left	Translation Right	774
		737	SP WINCH IN	SP WINCH OUT	756	BOOM LIFT	BOOM LOWER	775
		738			757	SWING CCW	SWING CW	776
		739			758	FLOOR ON	DIS-CHARGE ON	777
		740	1A 3A 	1A 3A 	759			778
		741	1B 3B 	1B 3B 	760			779
RADIO LATCH 1	RADIO LATCH 2	742	1C 6A 	1C 6A 	761	TELE-SCOPE OUT	TELE-SCOPE IN	780
PUSH PUSH LATCH	PUSH PUSH LATCH	743	1D 6B 	1D 6B 	762	ARM UP	ARM DOWN	781
MULTI OUT 1	MULTI OUT 2	744	1E 7A 	1E 7A 	763	SLEW LEFT	SLEW RIGHT	782
		745	1F 7B 	1F 7B 	764	SLEW LEFT	SLEW RIGHT	783
		746	2A 8A 	2A 8A 	765	TABLE UP	TABLE DOWN	784
		747	2B 8B 	2B 8B 	766	TRACK SPEED SLOW	TRACK SPEED FAST	785
		748	4A 9A 	4A 9A 	767	ENGINE START	IGNITION ON / OFF	786
		749	5A 9B 	5A 9B 	768			787
		750	UP	DOWN	769			788
		751	Leveling		770	WINCH DOWN	WINCH UP	789

CARRIAGE FORWARD 1	CARRIAGE REVERSE 2	790	FORWARD	REVERSE	809	ENGAGE STEER LOCKS	RELEASE STEER LOCK	828
TROLLEY LEFT 3	TROLLEY RIGHT 4	791	ON	OFF	810	YOKE OPEN	YOKE CLOSE	829
ARCH ROTATE 5	AUTO/MANUAL 6	792			811	BACK BAR UP	BACK BAR DOWN	830
AXEL 1 	AXEL 1 	793			812	BELLY BAND DOWN	BELLY BAND UP	831
AXEL 2 	AXEL 2 	794			813	LEGS UP	LEGS DOWN	832
AXEL 3 	AXEL 3 	795			814	BOOM RIGHT	BOOM LEFT	833
AXEL 4 	AXEL 4 	796			815	BOOM OUT	BOOM IN	834
ALL AXEL 	ALL AXEL 	797			816	VAC BREAKER OPEN	VAC BREAKER CLOSE	835
1 	2 	798			817	F1	F2	836
3 	4 	799			818	 V3	 V3	837
	WORK LIGHTS 	800			819	 MV	 MV	838
REAR G/NECK H/BOX DOWN	REAR G/NECK H/BOX UP	801			820		ENGINE STOP	839
STEER DOLLY H/BOX DOWN	STEER DOLLY H/BOX UP	802			821	START STOP		840
FRONT G/NECK H/BOX DOWN	FRONT G/NECK H/BOX UP	803			822	DRIBBLE BAR OPEN	DRIBBLE BAR CLOSE	841
JEEP HATBOX DOWN	JEEP HATBOX UP	804		POWER PACK	823	MACERATOR ON	MACERATOR OFF	842
AXLES RETRACT	AXLES EXPAND	805		RELEASE FRONT BRAKES	824	CHANGE OVER SPREAD	CHANGE OVER FILL	843
AXLES STEER LEFT	AXLES STEER RIGHT	806	REAR SUSP DOWN	REAR SUSP UP	825	SPREAD PLATE OPEN	SPREAD PLATE CLOSE	844
DS DOCK LEVELER UP	DS DOCK LEVELER DOWN	807	FRONT SUSP DOWN	FRONT SUSP UP	826	LINKAGE UP	LINKAGE DOWN	845
CS DOCK LEVELER UP	CS DOCK LEVELER DOWN	808	STEER RIGHT	STEER LEFT	827	TOP FILL OPEN	TOP FILL CLOSE	846

FILL ARM UP		FILL ARM DOWN	847	CAMERA 3		CAMERA 4	866	BACK GATE CLOSED		BACK GATE OPEN	885
FRONT VALVE OPEN		FRONT VALVE CLOSE	848	 HOIST		HOIST 	867	PUMP PRESS		PUMP VAC	886
PUSH		PULL	849	WINCH 		WINCH 	868	BOOM GATE CLOSED		BOOM GATE OPEN	887
MOTOR TIGHT		MOTOR LOOSE	850	ON LEFT FRONT ROLLERS		OFF LEFT FRONT ROLLERS	869	STEER YES		STEER NO	888
CYL TIGHT		CYL LOOSE	851	ON LEFT REAR ROLLERS		OFF LEFT REAR ROLLERS	870	AUX 1 OFF		AUX 1 ON	889
EXT		RET	852	ON RIGHT FRONT ROLLERS		OFF RIGHT FRONT ROLLERS	871	AUX 2 OFF		AUX 2 ON	890
 PRESS		 PRESS	853	ON RIGHT REAR ROLLERS		OFF RIGHT REAR ROLLERS	872	 UNLOCK		 LOCK	891
			854				873	FAST FORWARD		FAST REVERSE	892
		RAPID	855				874	LEVEL STOP START			893
MOTOR START STOP		LIGHTS ON-OFF	856				875	LOAD OUT OFF		LOAD OUT ON	894
RIGHT BOOM		LEFT BOOM	857				876	VIBRATOR 1 OFF		VIBRATOR 1 ON	895
BOOM OUT		BOOM IN	858	1 21		2 22	877	VIBRATOR 2 OFF		VIBRATOR 2 ON	896
VAC BREAKER OPEN		VAC BREAKER CLOSE	859	3 23		4 24	878	AIR DOOR OFF		AIR DOOR ON	897
BOOM UP		BOOM DOWN	860	5 25		6 26	879	LOCK UNLOCK		REAR HORN	898
AUTO			861	7 27		8 28	880				899
 FRONT		 FRONT	862	9 29		10 30	881	FORWARD AUTO HOME		TOP UP ROTATE TOP	900
LEVELING LEFT		LEVELING RIGHT	863	NOT USED		ENGINE START	882	REVERSE ROTATE Ts		TOP DOWN ROTATE SIDE	901
STEER LEFT		STEER RIGHT	864	MACHINE STOP		ENGINE STOP	883	LEFT OUT Ts1 OUT		LEFT IN Ts1 IN	902
CAMERA 1		CAMERA 2	865				884	RIGHT IN Ts2 IN		RIGHT OUT Ts2 OUT	903

			904				923				942
UNDER-RUN UP		UNDER-RUN DOWN	905				924				943
UNLOAD		LOAD	906				925				944
SPRAY		SWEEP	907	APPROACH RETRACT		APPROACH EXTEND	926				945
			908				927	FREE SPOOL		AUX	946
GATE 1 CLOSED		GATE 1 OPEN	909	GATE 1 OPEN		GATE 1 CLOSE	928	YOKE OPEN		YOKE CLOSE	947
GATE 2 CLOSED		GATE 2 OPEN	910	GATE 2 OPEN		GATE 2 CLOSE	929	BACK BAR UP		BACK BAR DOWN	948
SCRAPER GATE CLOSED		SCRAPER GATE OPEN	911	GATE 3 OPEN		GATE 3 CLOSE	930	BELLY BAND DOWN		BELLY BAND UP	949
SCRAPER UP		SCRAPER DOWN	912	GATE 4 OPEN		GATE 4 CLOSE	931				950
LEFT WING IN		LEFT WING OUT	913	GATE 5 OPEN		GATE 5 CLOSE	932				951
RIGHT WING IN		RIGHT WING OUT	914	FEEDER START		FEEDER STOP	933				952
			915	+ SPEED		- SPEED	934	POSITION 2		E-STOP	953
			916	HYD UNIT START		HYD UNIT STOP	935	POSITION 3		PULSE	954
			917	ENGINE AUTO START		ENGINE EMERGENCY STOP	936	POSITION 4		WATER	955
			918	ENGINE SPEED DECREASE		ENGINE SPEED INCREASE	937				956
			919	FL FR		RL RR	938				957
			920	FL RL		FR RR	939				958
			921	FL FR		RL RR	940				959
			922	FL RL		FR RR	941				960

FRONT GATE OPEN		FRONT GATE CLOSE	961	Engine Start STOP		Engine Start START	980				999
TILT OPEN		TILT CLOSE	962	Leveling Left Front UP		Leveling Left Front DOWN	981				1000
SQUEEZE SIDE OPEN		SQUEEZE SIDE CLOSE	963	Leveling Right Front UP		Leveling Right Front DOWN	982				1001
NECK BAR OPEN		NECK BAR CLOSE	964	Leveling Left Rear UP		Leveling Left Rear DOWN	983				1002
RUMP BAR OPEN		RUMP BAR CLOSE	965	Leveling Right Rear UP		Leveling Right Rear DOWN	984				1003
WINCH DRUM ENGAGED		WINCH DRUM FREE	966	Front Ext. Top Frame IN		Front Ext. Top Frame OUT	985	Wings		Wings	1004
VAC ON		VAC OFF	967	BARN SPINNER UP		BARN SPINNER DOWN	986	DOOR OPEN		DOOR CLOSE	1005
SWEeper GATE CLOSED		SWEeper GATE OPEN	968	JACK UP		JACK DOWN	987				1006
SWEeper UP		SWEeper DOWN	969	HYDRAULIC JACK UP		HYDRAULIC JACK DOWN	988				1007
LEFT LEG UP		LEFT LEG DOWN	970	PLAT IN		PLAT OUT	989				1008
RIGHT LEG UP		RIGHT LEG DOWN	971	PLAT UP		PLAT DOWN	990				1009
Dump UP		Dump DOWN	972	STAB UP		STAB DOWN	991	Hitch		Hitch	1010
Tongue Ext. IN		Tongue Ext. OUT	973	NMOD THROTTLE		UP THROTTLE	992	Wheels		Wheels	1011
Tail Ext. IN		Tail Ext. OUT	974			OFF/ON JETTER	993	Unit UP		Unit DOWN	1012
Rear Side-Shift LEFT		Rear Side-Shift RIGHT	975	UNO REEL		NI REEL	994	Ladder UP		Ladder DOWN	1013
Chain Drive FRONT		Chain Drive BACK	976	MAST LOCK		MAST UNLOCK	995	Platform IN		Platform OUT	1014
Sideway Left UP		Sideway Left DOWN	977				996				1015
Sideway Right UP		Sideway Right DOWN	978				997	Crane A		Crane B	1016
Sideway Drive LEFT		Sideway Drive RIGHT	979	Throttle			998	Crane AB UP		Crane AB DN	1017

S2	OUT	1018	Main Glycol Charge	Main Glycol Drain	1037	SPEC UP	SPEC DOWN	1056
	IN	1019	DUMP UP LEVEL LEFT FRONT UP	DUMP DN LEVEL LEFT FRONT DN	1038	THROTTLE UP/DOWN	BALE/LOG	1057
W	B	1020	TONGUE EXT IN LEVEL RIGHT FRONT UP	TONGUE EXT OUT LEVEL RIGHT FRONT DN	1039	E-STOP	AUTO CYCLE	1059
W	B	1021	TAIL EXT IN LEVEL LEFT REAR UP	TAIL EXT OUT LEVEL LEFT REAR DN	1040	LEFT LID CLOSE	LEFT LID OPEN	1060
Hopper OPEN	Hopper CLOSE	1022	REAR SIDE-SHIFT LEFT LEVEL RIGHT REAR UP	REAR SIDE-SHIFT RIGHT LEVEL RIGHT REAR DN	1041	RIGHT LID CLOSE	RIGHT LID OPEN	1060
Nav Lights	Aux	1023	CHAIN DRIVE FT FT EXT TOP FRAME IN	CHAIN DRIVE BK FT EXT TOP FRAME OUT	1042	RAM OUT	RAM IN	1061
Spec UP	Spec DOWN	1024	SIDEWAY LEFT UP BARN SPIN UP	SIDEWAY LEFT DN BARN SPIN DN	1043	FRONT LEFT LEG OUT	FRONT LEFT LEG IN	1062
Spec IN	Spec OUT	1025	SIDEWAY RIGHT UP JACK UP	SIDEWAY RIGHT DN JACK DN	1044	FRONT RIGHT LEG OUT	FRONT RIGHT LEG IN	1063
6	6	1026	SIDEWAY DRIVE LT MULE CARRIAGE IN	SIDEWAY DRIVE RT MULE CARRIAGE OUT	1045	REAR LEFT LEG OUT	REAR LEFT LEG IN	1064
7	7	1027	ENGINE STOP	ENGINE START	1046	REAR RIGHT LEG OUT	REAR RIGHT LEG IN	1065
8	8	1028	Luff In	Luff Out	1047	FRONT LEFT LEG DOWN	FRONT LEFT LEG UP	1066
9	9	1029	Boom	Boom	1048	FRONT RIGHT LEG DOWN	FRONT RIGHT LEG UP	1067
Main Lock	Main Open	1030	Blade	Blade	1049	REAR LEFT LEG DOWN	REAR LEFT LEG UP	1068
Full Bank	Part Bank	1031	Blade Extend	Blade Retract	1050	REAR RIGHT LEG DOWN	REAR RIGHT LEG UP	1069
Main Blowdown	S.B.F. Blowdown	1032	O/S Jack	O/S Jack	1051	ALL SIDE RAMS OUT	ALL SIDE RAMS IN	1070
S.B.F. Charge	Main Charge	1033	N/S Jack	N/S Jack	1052	ALL LEG RAMS DOWN	ALL LEG RAMS UP	1071
S.B.F. Lock	S.B.F. Open	1034	O/S Stabiliser	O/S Stabiliser	1053	PUMP ON OFF	PUMP REVERSE	1072
Charge Pump On	Charge Pump Off	1035	N/S Stabiliser	N/S Stabiliser	1054	PUMP PULSE	PUMP REVERSE PULSE	1073
SBF Glycol Charge	SBF Glycol Drain	1036	SPEC IN	SPEC OUT	1055	REVS HIGH LOW	HORN	1074

CLUTCH ON / OFF		CHOKE ON / OFF	1075	Left Ramp IN		Left Ramp OUT	1094	Door 7 ↑ Door 17 ↑		Door 7 ↓ Door 17 ↓	1113
CHOKER OPEN		CHOKER CLOSE	1076	Right Ramp IN		Right Ramp OUT	1095	Door 8 ↑ Door 18 ↑		Door 8 ↓ Door 18 ↓	1114
CONVEYOR 1 ON / OFF		FAST SLOW	1077	FOLD UP		FOLD DOWN	1096	Door 9 ↑ Door 19 ↑		Door 9 ↓ Door 19 ↓	1115
↓		↑	1078	TILT DOWN		TILT UP	1097	Door 10 ↑ Door 20 ↑		Door 10 ↓ Door 20 ↓	1116
TRAVEL ←		TRAVEL →	1079	EXTEND OUT		EXTEND IN	1098	Post UP		Post DOWN	1117
		HO/NO OFF	1080	Pump OFF		Pump ON	1099	BED SLIDE FORWARD		BED SLIDE BACKWARD	1118
RIGHT BOOM		LEFT BOOM	1081	Inlet Valve OFF		Inlet Valve ON	1100	BED TILT UP		BED TILT DOWN	1119
INO BOOM		NI BOOM	1082	Engine Speed DOWN		Engine Speed UP	1101	CLAWS OPEN		CLAWS CLOSE	1120
		BREAKER VAC	1083	FEED IN		FEED OUT	1102	Main Power ON/OFF		Light ON/OFF	1121
UP BOOM		NMOD BOOM	1084	Jaws UP		Jaws DOWN	1103	Belt Motor ON/OFF		Belt ON/OFF	1122
WINCH OUT		WINCH IN	1085	Shute		Shute	1104	🔒		🔒	1123
TOP DECK FRONT UP		TOP DECK FRONT DOWN	1086	STOP			1105	VAC Pump		Jetting Pump	1124
TOP DECK REAR UP		TOP DECK REAR DOWN	1087	Door 1-10 ↑ Door 11-20 ↑		Door 1-10 ↓ Door 11-20 ↓	1106	VAC		Press	1125
TAILGATE UP		TAILGATE DOWN	1088	Door 1 ↑ Door 11 ↑		Door 1 ↓ Door 11 ↓	1107	Reel IN		Reel OUT	1126
Kick UP		Kick DOWN	1089	Door 2 ↑ Door 12 ↑		Door 2 ↓ Door 12 ↓	1108	Revs UP		Revs DOWN	1127
Top Boom IN		Top Boom OUT	1090	Door 3 ↑ Door 13 ↑		Door 3 ↓ Door 13 ↓	1109	E-Stop			1128
Boom Extend IN		Boom Extend OUT	1091	Door 4 ↑ Door 14 ↑		Door 4 ↓ Door 14 ↓	1110	1. Aus		1. Ein	1129
Bed Extend IN		Bed Extend OUT	1092	Door 5 ↑ Door 15 ↑		Door 5 ↓ Door 15 ↓	1111	1. Links		Rechts 1.	1130
Neck Tilt UP		Neck Tilt DOWN	1093	Door 6 ↑ Door 16 ↑		Door 6 ↓ Door 16 ↓	1112	2. Aus		2. Ein	1131

ROOF OPEN		ROOF CLOSE	1132				1151	Deck DOWN		Deck UP	1171
DECK RAISE		DECK LOWER	1133	Throttle DOWN		Throttle UP	1153	O/S		N/S	1172
TAIL UP		TAIL DOWN	1134	Pump ON/OFF		Horn	1154	 O/S		 N/S	1173
1		2	1135				1155	RAIL GEAR WORK LIGHTS		RAIL GEAR ACTIVATE	1174
3		4	1136				1156	Engine START		Engine STOP	1175
5		6	1137	Arm IN		Arm OUT	1157	Speed INCREASE		Speed DECREASE	1176
7		8	1138	Arm UP		Arm DOWN	1158	Choke ENGAGE		Choke DISENGAGE	1177
9		10	1139	Clamp OPEN		Clamp CLOSE	1159	Dump Valve ENGAGE/ DISENGAGE			1178
TIP HOOKS RAISE		TIP HOOKS LOWER	1140	Rear OUT		Front OUT	1160	 O/S		 N/S	1179
		Fast Offload	1141	Rear FREE		Front FREE	1161	 O/S		 N/S	1180
			1142	Rear IN		Front IN	1162	 O/S		 N/S	1181
			1143	Arm IN		Arm OUT	1163	Yoke CLOSE		Yoke OPEN	1182
			1144	Arms		Arms	1164	Doors CLOSED		Doors OPEN	1183
			1145	Arms IN		Arms OUT	1165	Port Bow UP		Starboard Bow UP	1184
			1146	Tip Hook		Tip Hook	1166	Port Bow DOWN		Starboard Bow DOWN	1185
			1147	Fast Down		Throttle	1167	Port Stern UP		Starboard Stern UP	1186
			1148	Throttle OFF			1168	Port Stern DOWN		Starboard Stern DOWN	1187
			1149				1169	Main Valve OPEN		Main Valve CLOSE	1188
			1150	Bed DOWN		Bed UP	1170	Small Valve OPEN		Small Valve CLOSE	1189

Air Bags UP	Air Bags DOWN	1190	VAC PUMP STOP	VAC PUMP START	1209	Ejector Ram IN	Ejector Ram OUT	1228
Air Blast	Override	1191	MAIN PUMP STOP	MAIN PUMP START	1210	Cover Roll ON	Cover Roll OFF	1229
Landing UP	Landing DOWN	1192	MAIN PUMP ↑ UP	MAIN PUMP ↓ DOWN	1211	Cover Roll OFF	Cover Roll ON	1230
Tank OPEN	Tank CLOSE	1193			1212	Tail Door UP	Tail Door DOWN	1231
Main Pump OPEN	Main Pump CLOSE	1194			1213	Ejector Ram OUT	Ejector Ram IN	1232
Ball Chute OPEN	Ball Chute CLOSE	1195			1214			1233
		1196			1215	F. HR LOWER RAISE	R. HR LOWER RAISE	1234
		1197			1216	F. HR LOWER RAISE	R. HR LOWER RAISE	1235
		1198			1217	F. HR LOWER RAISE	R. HR LOWER RAISE	1236
		1199			1218	F. HR LOWER RAISE	R. HR LOWER RAISE	1237
		1200			1219	F. HR LOWER RAISE	R. HR LOWER RAISE	1238
BED SLIDE OFF	BED SLIDE ON	1201	Winch 1 IN 	Winch 1 OUT 	1220	FEEDER AND DISCHARGE START	FEEDER AND DISCHARGE STOP	1239
BED TILT DOWN	BED TILT UP	1202	Winch 2 IN 	Winch 2 OUT 	1221	Vibration EIN	Vibration AUS	1240
SPEC OUT	SPEC IN	1203	Lift UP 	Lift DOWN 	1222	Frequenz ▲	Frequenz ▼	1241
SPEC DOWN	SPEC UP	1204	Tele IN 	Tele OUT 	1223	Vibration EIN/AUS	Drehrichtung RECHTS/LINKS	1242
DOORS CLOSE 1	DOORS OPEN 1	1205	Hatch OPEN 	Hatch CLOSE 	1224			1243
DOORS CLOSE 2	DOORS OPEN 2	1206	Launch Port IN 	Launch Port OUT 	1225			1244
	Fast Offload	1207	Launch Starboard IN 	Launch Starboard OUT 	1226			1245
		1208	Trailer Tail Door UP 	Trailer Tail Door DOWN 	1227			1246

Ramp UP		Ramp DOWN	1247	PAN UP		PAN DOWN	1266	Roof UP ↑		Roof DOWN ↓	1285
← Ramp OUT		→ Ramp IN	1248	Eject UP		Eject DOWN	1267	Seat UP ↑		Seat DOWN ↓	1286
Leg UP		Leg DOWN	1249	Clamp		Unclamp	1268	FRONT WINCH IN		FRONT WINCH OUT	1287
F-TOW EYE LOWER RAISE		R-TOW EYE LOWER RAISE	1250	FREEWHEEL		SPARE	1269	REAR WINCH IN		REAR WINCH OUT	1288
L.O. BEAM IN OUT		R.O. BEAM IN OUT	1251	Steer UNLOCK		Steer LOCK	1270	Start Wickeln		Stop Wickeln	1289
L - JACK EXT RET		R - JACK EXT RET	1252	Swing Jack DOWN		Swing Jack UP	1271	TUB FORWARD		TUB REVERSE	1290
TABS. ON/OFF		OPTION ON/OFF	1253	LEFT WINCH IN		RIGHT WINCH IN	1272	Yoke IN		Yoke OUT	1291
Rüttlung EIN-AUS		Nach-Rütteln EIN-AUS	1254	LEFT WINCH OUT		RIGHT WINCH OUT	1273	Door OPEN		Door SHUT	1292
Rüttlung Frequenz ▲		Nach-Rütteln Frequenz ▲	1255	LIFT AXLE IN		LIFT AXLE OUT	1274	Squeeze IN		Squeeze OUT	1293
Rüttlung Frequenz ▼		Nach-Rütteln Frequenz ▼	1256	ROTATE LEFT		ROTATE RIGHT	1275	Back Bar IN		Back Bar OUT	1294
DOWN		UP	1257	JIG 2 IN		JIG 2 OUT	1276	DECK LOCK		DECK UNLOCK	1295
START		▲	1258	JIG 1 IN		JIG 1 OUT	1277	DECK RAISE		DECK LOWER	1296
STOP		▼	1259	MAN ON		MAN OFF	1278	RAMP RETRACT		RAMP EXTEND	1297
DRU WINCH IN		DRU WINCH OUT	1260	← Bow Thruster LEFT		Bow Thruster RIGHT →	1279	WINCH IN		WINCH OUT	1298
FREE SPOOL			1261	Main Drive FORWARD ↑		Main Drive BACK ↓	1280	FORWARD RAMP RETRACT		FORWARD RAMP EXTEND	1299
			1262	← Stern Thruster LEFT		Stern Thruster RIGHT →	1281	APPROACH RAMP RETRACT		APPROACH RAMP EXTEND	1300
			1263	Steering PORT ←		Steering STARBOARD →	1282			E-STOP	1301
BAG UP		BAG DOWN	1264	Engine IGN		Engine START	1283	▲		PULSE	1302
BAG IN		BAG OUT	1265	Throttle FAST ↑		Throttle Slow ↓	1284	▼		WATER	1303

		1304	R Nozzle UP	R Nozzle DOWN	1323			1342
		1305	R Nozzle LEFT	R Nozzle RIGHT	1324			1343
SLIDE IN	SLIDE OUT	1306	R Valve OPEN	R Valve CLOSE	1325			1344
L 	R 	1307	Start	Lights	1326			1345
L 	R 	1308	RPM RPM RPM	RPM RPM RPM	1327	 LIFT UP	 LIFT DOWN	1346
BED FRONT 	BED REAR 	1309	Shift LEFT	Shift RIGHT	1328	 GARAGE OPEN	 GARAGE CLOSE	1347
BED FRONT LOCK	BED REAR LOCK	1310	 	 	1329	 CRANE IN	 CRANE OUT	1348
BED FRONT 	BED REAR 	1311	 	 	1330	 CRANE TELE IN	 CRANE TELE OUT	1349
Aus	Ein	1312	 	 	1331	 CRANE UP	 CRANE DOWN	1350
-	+	1313	 	 	1332	LH Door OPEN	LH Door CLOSE	1351
		1314	D2 Fwd	D2 Back	1333	RH Door OPEN	RH Door CLOSE	1352
PRESSURE RELEASE		1315	D2 Rear 	D2 Rear 	1334	ARM UP	ARM DOWN	1353
SUPPORT LEG UP	SUPPORT LEG DOWN	1316	D3 Front 	D3 Front 	1335	BUCKET UP	BUCKET DOWN	1354
STEER LEFT	STEER RIGHT	1317	D3 Fwd	D3 Back	1336	TILT UP	TILT DOWN	1355
FEEDER SPEED +	FEEDER SPEED -	1318	D3 Rear 	D3 Rear 	1337			1356
VIBRATOR STOP	VIBRATOR START	1319	Aux 1	Aux 2	1338	Hold Air	Air In	1357
RPM +	RPM -	1320			1339			1358
F Nozzle UP	F Nozzle DOWN	1321			1340			1359
F Nozzle LEFT	F Nozzle RIGHT	1322			1341			1360

Release Latch Hook	Engage Latch Hook	1361	Out	In	1380	Rotator RIGHT	Rotator LEFT	1399
		1362	Unfold	Fold	1381	Grapple UP	Grapple DOWN	1400
Main Winch IN 	Main Winch OUT 	1363	Tele OUT	Tele IN	1382	EJECT UP	EJECT DOWN	1401
Blade IN	Blade OUT	1364	Slew PORT	Slew STBD	1383	CLAMP	UN-CLAMP	1402
Front Winch IN 	Front Winch OUT 	1365	EJECT UP	EJECT DOWN	1384			1403
Tail Retract	Tail Extend	1366	CLAMP	UN-CLAMP	1385			1404
Lock	Unlock	1367			1386	Axle Slide IN	Axle Slide OUT	1405
Beacon UP	Beacon DOWN	1368	RELEASE 	SQUEEZE 	1387	Axle Slide OUT	Axle Slide IN	1406
L1↑	L1↓	1369	FLOAT OFF - ON	LIGHT OFF - ON	1388	Underlift UP	Underlift DOWN	1407
L2↑	L2↓	1370	Float	Lock	1389	Underlift IN	Underlift OUT	1408
R1↑	R1↓	1371	Lights ON	Lights OFF	1390	Crane IN	Crane OUT	1409
R2↑	R2↓	1372	Centre		1391			1410
↑ UP	↓ DOWN	1373	Tower 1 RAISE	Tower 1 LOWER	1392			1411
FRONT - R 	FRONT - R 	1374	Tower 2 RAISE	Tower 2 LOWER	1393			1412
FRONT - L 	FRONT - L 	1375	Tilt DOWN	Tilt UP	1394			1413
REAR - R 	REAR - R 	1376	Main Boom UP	Main Boom DOWN	1395			1414
REAR - L 	REAR - L 	1377	Second Boom UP	Second Boom DOWN	1396			1415
O/S Pod 	O/S Pod 	1378	Telescope UP	Telescope DOWN	1397	BLADE 1 UP	BLADE 1 DOWN	1416
N/S Pod 	N/S Pod 	1379	Crane Slewing RIGHT	Crane Slewing LEFT	1398	BLADE 2 UP	BLADE 2 DOWN	1417

BLADE 3 UP		BLADE 3 DOWN	1418				1437				1456
BLADE 4 UP		BLADE 4 DOWN	1419				1438				1457
LEFT GATE OPEN		LEFT GATE CLOSED	1420				1439	Loader START		Loader STOP	1458
RIGHT GATE OPEN		RIGHT GATE CLOSED	1421				1440	Vibrator START			1459
LEFT PAD DOWN		LEFT PAD UP	1422	Vac Pump ON/OFF			1441	CW		ACW	1460
RIGHT PAD DOWN		RIGHT PAD UP	1423	Inlet Valve CLOSED		Inlet Valve OPEN	1442	SCR ON/OFF		SP-1	1461
Side OPEN		Side SQUEEZE	1424	RPM —		RPM +	1443	Reset		LMD	1462
Roll DOWN		Roll OVER	1425	Varsi Nosto		Varsi Lasku	1444	Lift Right Side		Let Down Right Side	1463
Sand Fwd		Sand Rev	1426	Kääntö Vasen		Kääntö Oikea	1445	Lift Left Side		Let Down Left Side	1464
4-10 Fwd		4-10 Rev	1427	Kääntö Nopeus +		Kääntö Nopeus -	1446	Front Lights		Rear Lights	1465
Raise Grill		Lower Grill	1428	Lukitus Päälle		Lukitus Pois	1447	Lock Axles Up		Fast	1466
			1429	Jyrsin Päälle		Jyrsin Pois	1448	Engine STOP		Engine START	1467
			1430	Yoke ↓		Yoke ↑	1449	Bed RAISE		Bed LOWER	1468
VACUUM  AIR			1431	Chute ←		Chute →	1450	Extension IN		Extension OUT	1469
			1432	Deflector ↓		Deflector ↑	1451	Tail LEFT		Tail RIGHT	1470
			1433	Feed Roll ←		Feed Roll →	1452	Deck 1 UP		Deck 1 DOWN	1471
Gate 1 OPEN		Gate 1 CLOSED	1434	Aux		Aux	1453	Deck 2 UP		Deck 2 DOWN	1472
Gate 2 OPEN		Gate 2 CLOSED	1435	Beacon On/Off		Lights On/Off	1454	Deck 3 UP		Deck 3 DOWN	1473
			1436	Spray ON		Spray OFF	1455	Beacons ON		Beacons OFF	1474

Opposite
is 222

GRIP	UNGRIP	1475			1494			1513
PITCH DOWN	PITCH UP	1476			1495			1514
LEFT OUT	LEFT IN	1477	Winch 2 IN	Winch 2 OUT	1496	ELEVATOR ON/OFF	HOPPER ON/OFF	1515
RIGHT OUT	RIGHT IN	1478	Water Pump ON	WORK LIGHTS	1497	ON/OFF	ON/OFF	1516
WINDOW OPEN GARAGE OPEN	WINDOW CLOSE GARAGE CLOSE	1479	Aux 1	VAC BREAKER	1498	DOOR 1 OPEN	DOOR 1 CLOSE	1517
BOOM IN LADDER UP	BOOM OUT LADDER DOWN	1480	Aux 2	ENGINE EMERGENCY STOP	1499	DOOR 2 OPEN	DOOR 2 CLOSE	1518
EXTEND ON	RETRACT OFF	1481	Pay OUT	Pay IN	1500	REAR LIGHTS	FRONT LIGHTS	1519
WINDOW OPEN	WINDOW CLOSE	1482	ENGINE STOP		1501			1520
CABLE UP	CABLE DOWN	1483			1502			1521
GARAGE OPEN	GARAGE CLOSE	1484			1503			1522
L SIDE ↑	R SIDE ↑	1485			1504			1523
Winch Port IN	Winch Port OUT	1486			1505			1524
Winch Starboard IN	Winch Starboard OUT	1487	Press 1 HORN	Press 1 PAUSE	1506			1525
Forward SLOW	Forward FAST	1488	Press 2 HORN	Press 2 PAUSE	1507	HOPPER UP	HOPPER DOWN	1526
Back SLOW	Back FAST	1489	Sheet OPEN	Sheet CLOSE	1508			1527
Intake UP	Intake DOWN	1490	Sweep IN	Flaps UP	1509	VIB. ON	VIB. OFF	1528
Discharge UP	Discharge DOWN	1491	Spray		1510		OPEN	1529
		1492			1511		CLOSE	1530
		1493			1512	TRANS UN-LOCK BLADE 1 DN	TRANS LOCK BLADE 1 UP	1531

TILT ATE BLADE 2 DN	TILT FWD BLADE 2 UP	1532	F DMD IN	F DMD OUT	1551	D5	D1	1570
LIFT DN BLADE 3 DN	LIFT UP BLADE 3 UP	1533	K ITCH IN	K ITCH OUT	1552	D7	D6	1571
R-STAB DN BLADE 4 DN	R-STAB UP BLADE 4 UP	1534	L IVING IN	L IVING OUT	1553		D8	1572
L-STAB DN L-GATE CLOSE	L-STAB UP L-GATE OPEN	1535	R DMD IN	R DMD OUT	1554		R1	1573
AUX 1 R-GATE CLOSE	AUX 2 R-GATE OPEN	1536	OUT F DMD	IN F DMD	1555			1574
AUX 3 L-PAD DN	AUX 4 L-PAD UP	1537	OUT BATH	IN BATH	1556	PORTE POGO	PORTE ENTREPOT	1575
WATER R-PAD DN	THROTTLE R-PAD UP	1538	OUT KITCH	IN KITCH	1557	AUX 1	AUX 2	1576
STEER LEFT	STEER RIGHT	1539	OUT LIVING	IN LIVING	1558	AUX 3	AUX 4	1577
FLOAT STEER	LOCK STEER	1540	OUT R DMD	IN R DMD	1559			1578
FRONT UP	FRONT DOWN	1541	1↑	1↓	1560			1579
LEFT DOWN	RIGHT DOWN	1542	2↑	2↓	1561	Avant	Avant	1580
LEFT UP	RIGHT UP	1543	3↑	3↓	1562	Arrière	Arrière	1581
GLOW PLUGS		1544	4↑	4↓	1563	DRILL JACK 2 ↑ DRILL JACK 2 ↓	DRILL JACK 3 ↑ DRILL JACK 3 ↓	1582
BED RAISE STEER LOCK	BED LOWER STEER UNLOCK	1545	5↑	5↓	1564	DRILL JACK 1 ↑ DRILL JACK 1 ↓	DRILL JACK 4 ↑ DRILL JACK 4 ↓	1583
WINCH IN STEER LEFT	WINCH OUT STEER RIGHT	1546	6↑	6↓	1565	ALL JACKS DRILLS ↑ ALL JACKS DRILLS ↓	DRILLS JACKS	1584
EXTENSION IN STROBE LIGHTS	EXTENSION OUT WORK LIGHT 1	1547	7↑	7↓	1566	PANS ↑ PANS ↓	LIFT PINS LIFT PINS	1585
TAIL LEFT WORK LIGHT 2	TAIL RIGHT WORK LIGHT 3	1548	8↑	8↓	1567	SIDE SHIFT FPP ← SIDE SHIFT FPP →	ROTATE FPP ← ROTATE FPP →	1586
		1549	9↑	9↓	1568	STEER CRANE ← STEER CRANE →	SIDE SHIFT HOIST ← SIDE SHIFT HOIST →	1587
		1550	10↑	10↓	1569	TRAVEL FWD TRAVEL BWD	HOIST ↑ HOIST ↓	1588

	EM STOP	1589	TAITTO	TAITTO	1608		1627
		1590	VEITSI	VEITSI	1609		 1628
L	R	1591	PUMPPU ON	PUMPPU OFF	1610		 1629
LOCK	LOCK	1592	TARP OPEN	TARP CLOSED	1611		 1630
UNLOCK	UNLOCK	1593	O/S FRONT 	O/S FRONT 	1612	SLEW BACK	SLEW FORWARD 1631
OPEN	OPEN	1594	N/S FRONT 	N/S FRONT 	1613	4/1	15/2 1632
CLOSE	CLOSE	1595	O/S REAR 	O/S REAR 	1614	CraneS LEFT	CraneS RIGHT 1633
DUMP	DUMP	1596	N/S REAR 	N/S REAR 	1615	RAMP 	RAMP  1634
SET	SET	1597	 STAIR PLATFORM OUT	 STAIR PLATFORM IN	1616	SCREEN DOWN	SCREEN UP 1635
		1598	 STAIR CANOPY OUT	 STAIR CANOPY IN	1617	SCREEN FOLD	SCREEN UNFOLD 1636
		1599	 N/S POD UNPACK SEQUENCE	 N/S POD PACK-UP SEQUENCE	1618	SCREEN ANTI CLOCK	SCREEN CLOCK WISE 1637
		1600	 O/S POD UNPACK SEQUENCE	 O/S POD PACK-UP SEQUENCE	1619	SPEAK IN	SPEAK OUT 1638
		1601		EMERGENCY STOP	1620	BANNER IN	BANNER OUT 1639
		1602	 N/S POD OUT	 N/S POD IN	1621	TOP BANNER DOWN	TOP BANNER UP 1640
		1603	 O/S POD OUT	 O/S POD IN	1622	FAST	SLOW 1641
		1604	 CENTRE ISLAND	 CENTRE ISLAND	1623	FILLER START	FILLER STOP 1642
		1605	 N/S FLOOR RAM UP	 N/S FLOOR RAM DOWN	1624	JAR STOP IN	JAR STOP OUT 1643
NOSTO	LASKU	1606	 O/S FLOOR RAM UP	 O/S FLOOR RAM DOWN	1625	DIVERT & INDIVERT	BROKEN JAR 1644
KÄÄNTÖ	KÄÄNTÖ	1607		DEADMAN SWITCH	1626	TWO SPEED	RPM 1645

MAIN LIFT UP		MAIN LIFT DOWN	1646	DOLLY LEFT		DOLLY RIGHT	1665	WASTE		AUX I	1684
FOLD UP		FOLD DOWN	1647	TAIL SHIFT LEFT		TAIL SHIFT RIGHT	1666	CRADLE IN		CRADLE OUT	1685
SWING IN WINCH 1 IN		SWING OUT WINCH 1 OUT	1648	START		STOP	1667	CRADLE UP		CRADLE DOWN	1686
UNDER-REACH EXTEND IN WINCH 2 IN		UNDER-REACH EXTEND OUT WINCH 2 OUT	1649	CLOSE 		OPEN 	1668	FRONT LEG RAISE SHEET SYSTEM RAISE		FRONT LEG LOWER SHEET SYSTEM LOWER	1687
TOP BOOM EXTEND IN		TOP BOOM EXTEND OUT	1650	LIGHTS 		LIGHTS 	1669	REAR LEG RAISE SHEET SYSTEM EXT RAISE		REAR LEG LOWER SHEET SYSTEM EXT LOWER	1688
STABILIZER UP		STABILIZER DOWN	1651				1670	CLAMPS OPEN SLIDE BARS OUT		CLAMPS CLOSE SLIDE BARS IN	1689
UP THROTTLE		DOWN THROTTLE	1652	ROOF UP SPLIT DECK UP		ROOF DOWN SPLIT DECK DOWN	1671	FORE MAST RAISE		FORE MAST LOWER	1690
		JETTER	1653	DECK TDF DECK WDF		DECK TDF DECK WDF	1672	MAIN MAST RAISE		MAIN MAST LOWER	1691
		BREAKER VAC	1654	DECK TDR DECK WDR		DECK TDR DECK WDR	1673	MIZZEN MAST RAISE		MIZZEN MAST LOWER	1692
BED RAISE ENGINE STOP		BED LOWER ENGINE START	1655				1674				1693
WINCH IN ENGINE CHOKE		WINCH OUT QUID FLASHERS	1656	SPLIT EXTEND WELL DECK EXTEND		SPLIT RETRACT WELL DECK RETRACT	1675				1694
EXTENSION IN		EXTENSION OUT	1657	EXTEND IN		EXTEND OUT	1676	BED TILT 		BED TILT 	1695
STEER LOCK		STEER UNLOCK	1658	DUMP 1 LIGHT		DUMP 2 LIGHT	1677	LIGHTS 		LIGHTS 	1696
STEER LEFT		STEER RIGHT	1659	SLIDE 1		SLIDE 2	1678	JETTER ON/OFF		E-STOP	1697
MULE IN		MULE OUT	1660	LIFT 1		BACKUP LIGHT	1679	T		N	1698
SLIDE 1 IN		SLIDE 1 OUT	1661	HOIST UP		HOIST DOWN	1680	A UP		A DOWN	1699
SLIDE 2 IN		SLIDE 2 OUT	1662	VACUUM		RECIRC	1681	B UP		B DOWN	1700
LEFT DOLLY DOWN		LEFT DOLLY UP	1663	HOFF 1 OIL 1		HOFF 1 OIL 2	1682	C UP		C DOWN	1701
RIGHT DOLLY DOWN		RIGHT DOLLY UP	1664	HOFF 2 OIL 1		HOFF 2 OIL 2	1683	D UP		D DOWN	1702

DECK RAMP IN	DECK RAMP OUT	1703	LIFT	DOWN PRESSURE	1722	AXLE 1 ←	AXLE 1 →	1741
FLOOR RAMP UP	FLOOR RAMP DOWN	1704	FEED ROLLER FWD	FEED ROLLER REV	1723	AXLE 2 ←	AXLE 2 →	1742
 RIGHT POD UNLOCK	 RIGHT POD LOCK	1705			1724	AXLE 3 ←	AXLE 3 →	1743
 LEFT POD UNLOCK	 LEFT POD LOCK	1706	 DS LEG	 DS LEG	1725	ALL AXLES ←	ALL AXLES →	1744
RAISE FLOOR 	LOWER FLOOR 	1707	 PS LEG	 PS LEG	1726	STAGING DOORS CLOSE	STAGING DOORS OPEN	1745
 HOIST UP	 HOIST DOWN	1708	BOOM DOWN	BOOM UP	1727	PUSH BAR DOWN	PUSH BAR UP	1746
TROLLEY EAST	TROLLEY WEST	1709	AXLE LEFT	AXLE RIGHT	1728	HEAD GATE CLOSE	HEAD GATE OPEN	1747
 BRIDGE NORTH	 BRIDGE SOUTH	1710	DRIVE REVERSE	DRIVE FORWARD	1729	LIFT ARM UP	LIFT ARM DOWN	1748
DECK WINCH 	DECK WINCH 	1711	SIDE UP	SIDE DOWN	1730	CAGE UP	CAGE DOWN	1749
ARM UP	ARM DOWN	1712	THROTTLE DOWN	THROTTLE UP	1731	LEFT REAR CLOSE	LEFT REAR OPEN	1750
SHIFT LEFT	SHIFT RIGHT	1713	JUMP LEFT	JUMP RIGHT	1732	RIGHT REAR CLOSE	RIGHT REAR OPEN	1751
FRONT UP	FRONT DOWN	1714	REEL IN	REEL OUT	1733	LEFT FRONT CLOSE	LEFT FRONT OPEN	1752
RIGHT UP	RIGHT DOWN	1715	WATER PUMP ON	WATER PUMP OFF	1734	RIGHT FRONT CLOSE	RIGHT FRONT OPEN	1753
LEFT UP	LEFT DOWN	1716	REAR VALVE OPEN	REAR VALVE CLOSE	1735	LEG LATCH RELEASE	COW RELEASE	1754
IGNITION ON / OFF	ENGINE START	1717	REEL OUT	REEL IN	1736	LEG 1 UP	LEG 1 DOWN	1755
		1718	PRESSURE	VACUUM	1737	LEG 2 UP	LEG 2 DOWN	1756
DIVERTER	START STOP	1719	BEACONS	CABIN LIGHTS	1738	LEG 3 UP	LEG 3 DOWN	1757
SPOUT DEFLECTOR FWD	SPOUT DEFLECTOR REV	1720	FRONT SPOT LEFT	FRONT SPOT RIGHT	1739	LEG 4 UP	LEG 4 DOWN	1758
SPOUT LEFT	SPOUT RIGHT	1721	REAR SPOT LEFT	REAR SPOT RIGHT	1740	SIDE UP	SIDE DOWN	1759

SHEET SYSTEM RAISE	SHEET SYSTEM LOWER	1760			1779			1798
SHEET SYSTEM EXT-RAISE	SHEET SYSTEM EXT-LOWER	1761			1780			1799
SLIDE BARS OUT	SLIDE BARS IN	1762			1781			1800
OS	OS	1763			1782			1801
NS	NS	1764			1783			1802
F	F	1765	TOP BOX 	TOP BOX 	1784			1803
		1766	TOP SKIN 	TOP SKIN 	1785	1 16	2 17	1804
		1767			1786	3 18	4 19	1805
		1768			1787	5 20	6 21	1806
		1769			1788	7 22	8 23	1807
		1770			1789	9 24	10 25	1808
		1771			1790	11 26	12 27	1809
		1772	GRIZZLY START	+ SPEED	1791	13 28	14 29	1810
		1773	GRIZZLY STOP	- SPEED	1792	15 30		1811
		1774	 DOOR DOWN	 DOOR UP	1793	FAST	REAR	1812
		1775	 DOOR UNFOLD	 DOOR FOLD	1794	PRT	STBD	1813
		1776	 1	 2	1795			1814
		1777			1796			1815
		1778			1797	BED ON	BED OFF	1816

BED WINCH IN	BED WINCH OUT	1817			1836			1855
FRONT WINCH IN	FRONT WINCH OUT	1818			1837	RIGHT SIDE UP	RIGHT SIDE DOWN	1856
LOWER DOWN	LOWER UP	1819	BED OUT	BED IN	1838	LEFT SIDE UP	LEFT SIDE DOWN	1857
LOWER IN	LOWER OUT	1820	WHEEL LIFT DOWN	WHEEL LIFT UP	1839	AUX	LOCK FRONT AXLE	1858
		1821	WHEEL LIFT OUT	WHEEL LIFT IN	1840	BLINK LIGHT	FAST	1859
		1822	WINCH OUT	WINCH IN	1841	FRONT LIGHT	REAR LIGHT	1860
		1823			1842	Dead man	 LIGHTS	1861
ENGINE STOP		1824	ROTATE ON	ROTATE OFF	1843	DOVE TAIL UP	DOVE TAIL DOWN	1862
		1825			1844			1863
		1826			1845			1864
DEADMAN SWITCH	DEADMAN SWITCH	1827			1846	SHIFT		1865
		1828			1847	START STOP		1866
		1829	ALIGNMENT	PRESSURE	1848			1867
		1830	HIGH PRESSURE	LOW PRESSURE	1849	GRIZZLY DUMP	REMOTE STOP	1868
EXTENSION 1 IN	EXTENSION 1 OUT	1831	PRESSURE WASHER ON	PRESSURE WASHER OFF	1850	EXTENSION IN	EXTENSION OUT	1869
EXTENSION 2 IN	EXTENSION 2 OUT	1832			1851	QUAD FLASHERS		1870
TAIL LEFT	TAIL RIGHT	1833			1852	FAST	WORKING LIGHTS	1871
LOCK FRONT AXLES	LOCK REAR AXLES	1834			1853			1872
WORKING LIGHTS	FAST	1835			1854			1873

			1874	HOIST UP SLOW		HOIST UP FAST	1893			1912
CONVEYOR 1 START		CONVEYOR 1 STOP	1875	ENABLE		PRE- CHARGE	1894			1913
CONVEYOR 2 START		CONVEYOR 2 STOP	1876	AUTO STEER		MANUAL STEER	1895			1914
AUX 1		AUX 2	1877	ENGINE START		ENGINE ON/OFF	1896	RAMP 1 DOWN	RAMP 1 UP	1915
			1878	RIGHT STEER REAR		LEFT STEER REAR	1897	RAMP 2 DOWN	RAMP 2 UP	1916
			1879	RIGHT STEER FRONT		LEFT STEER FRONT	1898	RAMP 3 DOWN	RAMP 3 UP	1917
Rear Winch IN 		Rear Winch OUT 	1880				1899	RAMP 4 DOWN	RAMP 4 UP	1918
PORT FORE WINCH IN		PORT FORE WINCH OUT	1881				1900	RAMP 5 DOWN	RAMP 5 UP	1919
PORT AFT WINCH IN		PORT AFT WINCH OUT	1882	ENGINE ARM ENGINE STOP		ENGINE CRANK	1901	BRAKE		1920
STBD FORE WINCH IN		STBD FORE WINCH OUT	1883				1902	CRUSH DOWN	CRUSH UP	1921
STBD AFT WINCH IN		STBD AFT WINCH OUT	1884	REVS UP		REVS DOWN	1903	LIFT BUMPER	LOWER BUMPER	1922
PORT BOW WINCH IN		PORT BOW WINCH OUT	1885	PRESSURE ON		PRESSURE OFF	1904	RAISE DOOR	LOWER DOOR	1923
STBD BOW WINCH IN		STBD BOW WINCH OUT	1886	UNLOAD		LOAD	1905	UNLOAD	LOAD	1924
PORT INSIDE WINCH IN		PORT INSIDE WINCH OUT	1887	WINCH IN		WORK LIGHTS	1906	RETRACT SWEEP		1925
PORT OUTSIDE WINCH IN		PORT OUTSIDE WINCH OUT	1888	DOOR UP		DOOR DOWN	1907	OPEN SHEET	CLOSE SHEET	1926
STBD INSIDE WINCH IN		STBD INSIDE WINCH OUT	1889	UNDER- RUN UP		UNDER- RUN DOWN	1908	F _{IN}	F _{OUT}	1927
STBD OUTSIDE WINCH IN		STBD OUTSIDE WINCH OUT	1890	COVER OPEN		COVER CLOSED	1909	R _{IN}	R _{OUT}	1928
			1891	GRIZZLY DUMP		REMOTE STOP	1910	WINCH 1 IN	WINCH 1 OUT	1929
HOIST DOWN SLOW		HOIST DOWN FAST	1892				1911	WINCH 2 IN	WINCH 2 OUT	1930

		1931	GO			1950			1969
WEB ON/OFF	SPINNER ON/OFF	1932	11 31		12 32	1951			1970
WEB INCREASE	SPINNER INCREASE	1933	13 33		14 34	1952	VERRIDE TILT DOWN		1971
WEB DECREASE	SPINNER DECREASE	1934	15 35		16 36	1953	DOOR OPEN	SWEEP WINCH	1972
WINCH	DECK	1935	17 37		18 38	1954	LHS NET OPEN	RHS NET OPEN	1973
ALL 	ALL 	1936	19 39		20 40	1955	LHS NET CLOSE	RHS NET CLOSE	1974
SIDWAY DRIVE LT	SIDWAY DRIVE RT	1937	ON OFF		START	1956	BUMPER UP	BUMPER CLOSE	1975
		1938	MANUAL		AUTO	1957	UNLOAD EJECT	LOAD RETRACT	1976
		1939	PRE- CHARGE		ENABLE	1958			1977
DOOR UNFOLD	DOOR FOLD	1940	STEER LEFT		STEER RIGHT	1959			1978
DECK LEVEL	DECK LEVEL	1941	FRONT NECK X-BRACE OUT		FRONT NECK X-BRACE IN	1960	AUS PLATEAU	AUS EIN	1979
HAND	AUTO	1942	FRONT NECK C-MEMBER OUT		FRONT NECK C-MEMBER OUT	1961	NECK AUS	NECK EIN	1980
SCREEN 1 START	SCREEN 2 START	1943	FRONT NECK C-MEMBER IN		FRONT NECK C-MEMBER OUT	1962	AUS	EIN	1981
LIFT UP	LIFT DOWN	1944	FRONT BOX UP		FRONT BOX DOWN	1963	AB	AUF	1982
DRIVE FORWARD	DRIVE REVERSE	1945	REAR BOX UP		REAR BOX DOWN	1964	REAR LIGHTS	FASTER WORKING	1983
GRAB OPEN	GRAB CLOSE	1946	REAR NECK X-BRACE OUT		REAR NECK X-BRACE IN	1965	FRONT ENTRANCE STEPS LOWER	FRONT ENTRANCE STEPS RAISE	1984
JOG FWD	JOG REV	1947	REAR NECK C-MEMBER OUT		REAR NECK C-MEMBER OUT	1966	REAR ENTRANCE STEPS LOWER	REAR ENTRANCE STEPS RAISE	1985
CON 1	FLIP	1948	REAR NECK C-MEMBER IN		REAR NECK C-MEMBER OUT	1967	SAT DISH	SAT DISH	1986
LIFT / CATCH START	E-STOP	1949				1968	FRONT IN	FRONT OUT	1987

REAR IN		REAR OUT	1988	22/1		23/1	2007	HIGH SPEED		WORK LIGHT	2026
ENGINE STOP BED RAISE		ENGINE START BED LOWER	1989	4/1		15/2	2008	TILT LEFT		ROTATE LEFT	2027
ENGINE CHOKE CHAIN FWD		STROBES CHAIN REV	1990	9/1			2009	TILT RIGHT		ROTATE RIGHT	2028
EXT 1 IN EXT 2 IN		EXT 1 OUT EXT 2 OUT	1991				2010	CLAMP OPEN		VIBRO START	2029
STEER LOCK WINCH IN		STEER UNLOCK WINCH OUT	1992				2011	CLAMP CLOSE		VIBRO STOP	2030
STEER LEFT TAIL LEFT		STEER RIGHT TAIL RIGHT	1993				2012	VIBRO PTO		CLAMP PTO	2031
7		D	1994				2013				2032
			1995	RELEASE			2014				2033
DOOR OPEN			1996	PUMP 			2015				2034
PSI UP		PSI DOWN	1997				2016				2035
			1998	CONTAINER ON		CONTAINER ON	2017				2036
BED ON TOP DECK DOWN		BED OFF TOP DECK UP	1999	BREAKS ON/OFF		AUX ON/OFF	2018				2037
S1		S2	2000	WINCH FWD		WINCH REV	2019				2038
S3		13/1	2001	SLOW SPEED FWD HORN		SLOW SPEED REV HORN	2020	WALKWAY 1 UP		WALKWAY 1 DOWN	2039
7/1		9/2	2002	FAST SPEED FWD HORN		FAST SPEED REV HORN	2021	WALKWAY 2 UP		WALKWAY 2 DOWN	2040
10/1		10/2	2003	STEER LEFT 		STEER RIGHT 	2022	CANOPY UP		CANOPY DOWN	2041
11/2		15/1	2004	TILT UP		ARM UP	2023	TOP SIGN UP		TOP SIGN DOWN	2042
8/2		15/4	2005	TILT DOWN		ARM DOWN	2024	LITTLE TOP SIGN UP		LITTLE TOP SIGN DOWN	2043
16/1		16/3	2006	SHIFT LEFT		SHIFT RIGHT	2025				2044

		2045			2064			2083
		2046			2065			2084
		2047			2066			2085
MAIN FLOOR UP	MAIN FLOOR DOWN	2048	CONVEYOR	REVERSE	2067	LIGHT	CONVEY PAUSE	2086
BOAT UP	BOAT DOWN	2049	FAST	SLOW	2068		DECK LOGS	2087
FRONT FLOOR UP	FRONT FLOOR DOWN	2050	LIGHT		2069			2088
SLIDE UP	SLIDE DOWN	2051			2070			2089
ENGINE STOP BED RAISE	ENGINE START BED LOWER	2052	RELEASE	SQUEEZE	2071			2090
ENGINE CHOKE WINCH IN	WINCH FREE-SPOOL WINCH OUT	2053	LIFT	LIFT	2072	LEFT SIDE TELE UP	LEFT SIDE TELE DOWN	2091
EXT. 1 IN EXT 2 IN	EXT. 1 OUT EXT 2 OUT	2054	CLOSE	OPEN	2073	RIGHT SIDE TELE UP	RIGHT SIDE TELE DOWN	2092
STEER LOCK EXT 3 IN	STEER UNLOCK EXT 3 OUT	2055	ENGINE STOP STEER LOCK	ENGINE START STEER UNLOCK	2074	Winch 3 IN	Winch 3 OUT	2093
STEER LEFT TAIL LEFT	STEER RIGHT TAIL RIGHT	2056	BED RAISE STEER LEFT	BED LOWER STEER RIGHT	2075	Winch 4 IN	Winch 4 OUT	2094
WINGS Ignition	WINGS Crank	2057	WINCH IN STROBES	WINCH OUT	2076	Winch 5 IN	Winch 5 OUT	2095
		2058	EXTENSION IN	EXTENSION OUT	2077	Winch 6 IN	Winch 6 OUT	2096
		2059	TAIL LEFT	TAIL RIGHT	2078	Winch 7 IN	Winch 7 OUT	2097
START CONVEYOR	STOP CONVEYOR	2060	FILLER START	FILLER STOP	2079	Winch 8 IN	Winch 8 OUT	2098
START VIBRATOR	STOP VIBRATOR	2061	JAR SHOP IN	JAR SHOP OUT	2080	6	6	2099
DECK 1	DECK 1	2062	DIVERT/INDIVERT	BROKEN JAR	2081	7	7	2100
DECK 1	DECK 1	2063	DECK UP ROOF UP	DECK DOWN ROOF DOWN	2082	WINCH O/S	WINCH N/S	2101

S.C.L UP	S.C.L DOWN	2102	WHEEL DOWN LIFT	WHEEL OUT LIFT	2121			2140
S.C.L IN	S.C.L OUT	2103	LEFT TILT	LEFT ROTATE	2122	BRAKE OFF	BRAKE ON	2141
WINCH IN PRT SIDE	WINCH OUT PRT SIDE	2104	RIGHT TILT	RIGHT ROTATE	2123	FREQUENZ AUF	FREQUENZ AB	2142
WINCH IN STBD SIDE	WINCH OUT STBD SIDE	2105	CLAMP OPEN	CLAMP START VIBRO	2124	GRUPPE VOR	GRUPPE ZURÜCK	2143
RAMP UP	RAMP DOWN	2106	CLAMP CLOSE	STOP VIBRO	2125			2144
BOOM OUT PRT SIDE	BOOM IN PRT SIDE	2107	PTO VIBRO	PTO CLAMP	2126	STAGING DOORS OPEN	STAGING DOORS CLOSE	2145
BOOM OUT STBD SIDE	BOOM IN STBD SIDE	2108			2127	DOOR 3 OPEN	DOOR 3 CLOSE	2146
DOOR OPEN PRT SIDE	DOOR CLOSE PRT SIDE	2109			2128	DOOR 4 OPEN	DOOR 4 CLOSE	2147
DOOR OPEN STBD SIDE	DOOR CLOSE STBD SIDE	2110	CONVEYOR	CONVEYOR REVERSE	2129			2148
CONV ON	CONV OFF	2111	CONVEYOR SLOW	CONVEYOR FAST	2130	ENGINE START		2149
CONVEYOR UP	CONVEYOR DOWN	2112	LIGHT	FLOOR PAUSE	2131	STEER LOCK		2150
VIBR ON	VIBR OFF	2113	FLOOR FAST	FLOOR SLOW	2132	TOWER LOCK		2151
FWD 2	REV 2	2114	UP	BOOM UP	2133	BOTH EXT OUT	FAST OFFLOAD	2152
FWD 1		2115	DOWN	BOOM DOWN	2134	BOTH EXT IN	RIGHT EXT IN	2153
RECOVERY IN WINCH	RECOVERY OUT WINCH	2116	DUMP OPEN	DUMP CLOSE	2135	LEFT EXT OUT	RIGHT EXT OUT	2154
LEFT UP LEG	RIGHT UP LEG	2117	WATER	WHEY	2136	LEFT EXT IN		2155
LEFT DOWN LEG	RIGHT DOWN LEG	2118	MOLASSES		2137	LEFT LEG DOWN	RIGHT LEG DOWN	2156
DECK IN WINCH	DECK OUT WINCH	2119			2138	LEFT LEG UP	RIGHT LEG UP	2157
WHEEL UP LIFT	WHEEL IN LIFT	2120			2139	RH FRONT JACK UP	RH FRONT JACK DOWN	2158

		2216			2235	REAR CANOPY CLOSE	REAR CANOPY OPEN	2254
		2217			2236	REAR STAIRS UP	REAR STAIRS DOWN	2255
TANK REVERSE	TANK ON	2218			2237	LH FLOOR UP	LH FLOOR DOWN	2256
REVERSE TANK ELEVATOR	TANK ELEVATOR ON	2219	PLOW RETRACT	BUMPER UP/ DOWN	2238	RH FLOOR UP	RH FLOOR DOWN	2257
REVERSE DE-STONE ELEVATOR	DE-STONE ELEVATOR ON	2220	GATE OPEN	GATE CLOSE	2239	RH FRONT FLOOR UP	RH FRONT FLOOR DOWN	2258
SIDE ELEVATOR IN	SIDE ELEVATOR OUT	2221	ROOF CLOSE	ROOF OPEN	2240	SCREEN CANOPY CLOSE	SCREEN CANOPY OPEN	2259
STONE ELEVATOR RAISE	STONE ELEVATOR LOWER	2222	FLOOR OUT	FLOOR IN	2241	FOLD BOOM IN	UNFOLD BOOM OUT	2260
CRUSH UP	CRUSH DOWN	2223	BOTH UP	BOTH DOWN	2242	W/L IN L/W IN	W/L OUT R/W IN	2261
		2224	ENTRY BARRIER OPEN	ENTRY BARRIER CLOSE	2243	CLAWS CLOSE L/W OUT	CLAWS OPEN R/W OUT	2262
		2225	EXIT BARRIER OPEN	EXIT BARRIER CLOSE	2244	RH FRONT OUTRIGGER IN	RH FRONT OUTRIGGER OUT	2263
		2226	A	B	2245	LH FRONT OUTRIGGER IN	LH FRONT OUTRIGGER OUT	2264
		2227	C	D	2246	RH REAR OUTRIGGER IN	RH REAR OUTRIGGER OUT	2265
		2228	DRUM ON/OFF	GATE 1 OPEN/SHUT	2247	LH REAR OUTRIGGER IN	LH REAR OUTRIGGER OUT	2266
		2229	GATE ALL OPEN	GATE 2 OPEN/SHUT	2248	PEDESTAL UP	PEDESTAL DOWN	2267
		2230	GATE ALL SHUT	GATE 3 OPEN/SHUT	2249	DEADMAN	AUTO LEVEL	2268
		2231		GATE 4 OPEN/SHUT	2250	WHEEL UP LIFT	WHEEL DOWN LIFT	2269
		2232		GATE 5 OPEN/SHUT	2251	WHEEL IN LIFT	WHEEL OUT LIFT	2270
	6,8 to BREMSE Auf	2233	Sled IN	Sled OUT	2252	DS UP	DS DOWN	2271
		2234	RH FRONT POD CLOSE	RH FRONT POD OPEN	2253	PS UP	PS DOWN	2272

BACK UP		BACK DOWN	2273	DS JACK LEG UP		PS JACK LEG UP	2292	DSF UP		DSF DOWN	2311
HOIST UP TAIL IN		HOIST DOWN TAIL OUT	2274	BLACK WINCH IN		SILVER WINCH IN	2293	PSB UP		PSB DOWN	2312
CONTAINER ON GANTRY UP		CONTAINER OFF GANTRY DOWN	2275	BLACK WINCH OUT		SILVER WINCH OUT	2294	PSF UP		PSF DOWN	2313
BRAKES ON/OFF TARP IN		AUX ON/OFF TARP OUT	2276	BLACK WINCH FREESPOOL		SILVER WINCH FREESPOOL	2295	PSB UP		PSB DOWN	2314
FLOOR ON/OFF		FLOOR PAUSE	2277	DRIVERS SPADE DOWN		PASSENGER SPADE DOWN	2296	PS FLOOR UP		PS FLOOR DOWN	2315
FLOOR SLOW		FLOOR FAST	2278	DRIVERS SPADE UP		PASSENGER SPADE UP	2297	DS FLOOR UP		DS FLOOR DOWN	2316
CONVEYOR ON/OFF		CONVEYOR REVERSE	2279	TILT IN		TILT OUT	2298	JOCKEY UP		JOCKEY DOWN	2317
CONVEYOR FOLD		LIGHT	2280	CRANE BOOM IN		CRANE BOOM OUT	2299	HYD JACKS UP		HYD JACKS DOWN	2318
BEACON		WORK LIGHTS	2281	VACUUM ①		ENGINE EMERGENCY STOP	2300	DRAWBAR OPEN		DRAWBAR CLOSE	2319
R3↑		R3↓	2282	WATER ①		AUX	2301	MOWER UP		MOWER DOWN	2320
R4↑		R4↓	2283	↓		↑	2302	FLOOR ON		LIGHTS	2321
R5↑		R5↓	2284	↓		↑	2303	DRU IN WINCH		DRU OUT WINCH	2322
AUX		RIDE HEIGHT	2285	↓		↑	2304	DRU FREESPOOL WINCH		DRU 2 SPEED WINCH	2323
AUX		BLINK LIGHT	2286	↓		↑	2305	PUMP OFF		PUMP ON	2324
↑ RAISE		↓ LOWER	2287	STOP		STACKER START	2306	RELEASE		MOTOR OFF	2325
DS WINCH IN BOOM UP		PS WINCH IN BOOM IN	2288	LONG BELT START		MANUAL ALARM	2307	SLIDE ←		SLIDE →	2326
DS WINCH OUT BOOM DOWN		PS WINCH OUT BOOM OUT	2289			SHIFT	2308	SPEC WINCH OUT		SPEC WINCH IN	2327
DS WINCH FREESPOOL W/L FOLD		PS WINCH FREESPOOL W/L IN	2290	PREV		PFWD	2309	RAMP ←		RAMP →	2328
DS JACK LEG DOWN W/L UNFOLD		PS JACK LEG DOWN W/L OUT	2291	AREV		AFWD	2310	NOZZLE DOWN BOOM DOWN		NOZZLE UP BOOM UP	2329

NOZZLE LEFT BOOM LEFT	NOZZLE RIGHT BOOM RIGHT	2330	A	B	2349	GERNI ON OFF	AIR VALVE ON OFF	2368
ELBOW DOWN ORIG DOWN	ELBOW UP ORIG UP	2331	C	D	2350	JETTER ON OFF		2369
PUMP DOWN PUMP DOWN	PUMP UP PUMP UP	2332			2351	TANK UP	TANK DOWN	2370
AGITATE LEG IN	FILL LEG OUT	2333	GATE DOWN	GATE UP	2352			2371
		2334	BELT LEFT	BELT RIGHT	2353			2372
		2335	FRONT JACKS IN	FRONT JACKS OUT	2354			2373
		2336	UNIT UP	UNIT DOWN	2355			2374
		2337	SLIDING ROOF IN	SLIDING ROOF OUT	2356	★	▶/	2375
		2338	ROOF LOWER	ROOF RAISE	2357	STOP		2376
		2339	FLOOR UP	FLOOR DOWN	2358	MAIN CONV START	STINGER START	2377
SLIDER	SLIDER	2340	BELT START	BELT STOP	2359	MAIN CONV STOP	STINGER STOP	2378
LIFT	LIFT	2341	VIBRATOR START	VIBRATOR STOP	2360	CONV RAISE	HYD PUMP START	2379
CHAIN	CHAIN	2342	REEL IN	ENGINE STOP	2361	CONV LOWER	HYD PUMP STOP	2380
CABLE	CABLE	2343	LH CANOPY OPEN	LH CANOPY CLOSE	2362	STINGER EXTEND	STINGER RETRACT	2381
RAM 1 UP	RAM 1 DOWN	2344	RH CANOPY OPEN	RH CANOPY CLOSE	2363	TRAVEL LEFT	TRAVEL RIGHT	2382
RAM 2 UP	RAM 2 DOWN	2345			2364	EIN Bereich 1	AUS Bereich 1	2383
RAM 3 UP	RAM 3 DOWN	2346			2365	EIN Bereich 2	AUS Bereich 2	2384
RAM 4 UP	RAM 4 DOWN	2347	CHUTE UP	CHUTE DOWN	2366	EIN Bereich 3	AUS Bereich 3	2385
ALL RAMS UP	ALL RAMS DOWN	2348	HEAD LOCK CLOSE	HEAD LOCK OPEN	2367	5		2386

		2387	SCREEN UNFOLD		2406	W/L FOLD	W/L UNFOLD	2425
		2388	SCREEN ANTI CLOCK		2407	PUMP ON	PUMP OFF	2426
NORTH CONV TRAVEL LEFT	NORTH CONV TRAVEL RIGHT	2389			2408	AUX		2427
SOUTH CONV TRAVEL LEFT	SOUTH CONV TRAVEL RIGHT	2390			2409	T.D. ROLLER UP/DOWN		2428
GRUPPE 	GRUPPE 	2391	IN	OUT	2410	B.D. ROLLER UP/DOWN		2429
STOP/ START	BLEND	2392		X	2411	P.D. ROLLER UP/DOWN		2430
START BLEND DIRECT	LOADOUT	2393			2412	PLATFORM UP	PLATFORM DOWN	2431
LOADOUT CONVEYOR STOP/ START	LOADOUT	2394			2413	INTERIOR LIGHTS	MUTE	2432
HOPPER CONVEYOR STOP/ START	HOPPER	2395			2414	PILE 1A/1F	PILE 2A/2F	2433
TRANSFER CONVEYOR STOP/ START	TRANSFER	2396			2415	PILE 1B/1R	PILE 2B/2R	2434
GATE 1 CLOSE	GATE 1 OPEN	2397			2416	PILE 1C	PILE 2C	2435
GATE 2 CLOSE	GATE 2 OPEN	2398			2417	STOP	GO	2436
VIBRATOR 1	VIBRATOR 2	2399	Vibration EIN/AUS		2418	LOAD	AGITATE	2437
LEGS OUT	LEGS IN	2400			2419	NOZZLE LEFT	NOZZLE RIGHT	2438
N/S FRONT DOWN	N/S FRONT UP	2401			2420	SPOUT UP	SPOUT DOWN	2439
O/S FRONT DOWN	O/S FRONT DOWN	2402			2421	LIFT IN	LIFT OUT	2440
N/S REAR DOWN	N/S REAR UP	2403			2422	TRAILER FWD	TRAILER REV	2441
O/S REAR DOWN	O/S REAR DOWN	2404			2423	LEFT MOTOR FWD	RIGHT MOTOR FWD	2442
SCREEN UP	SCREEN DOWN	2405	W/L IN	W/L OUT	2424	LEFT MOTOR REV	RIGHT MOTOR REV	2443

MAIN TAIL UP		MAIN TAIL DOWN	2444			2463	JETTER ON/OFF	BACK PUMP ON/OFF	2482
FLIP TAIL IN		FLIP TAIL OUT	2445	1 2		2464			2483
H-BAR UP		H-BAR DOWN	2446	FRONT SUPPORT LEG DN 1 FRONT SUPPORT LEG UP 2	REAR SUPPORT LEG DN 1 REAR SUPPORT LEG UP 2	2465			2484
MOTOR GRADER UP		MOTOR GRADER DOWN	2447	1 2	1 2	2466			2485
			2448	RAMP 	RAMP 	2467			2486
			2449			2468			2487
			2450	UP	DOWN	2469	WASHER STOP	WASHER START	2488
			2451	LEFT	RIGHT	2470	SUCK	BLOW	2489
			2452	IN	OUT	2471			2490
			2453	PUMP ON	PUMP OFF	2472		Fast Offload	2491
			2454	LIGHTS ON	AUX	2473	WINCH STOP	WINCH FWD	2492
			2455	FRONT 	FRONT 	2474		WINCH REV	2493
			2456	REAR 	REAR 	2475	Gate 1 Open	Gate 1 Close	2494
			2457	FRONT 	REAR 	2476	Gate 2 Open	Gate 2 Close	2495
			2458	FRONT 	REAR 	2477	Incline Belt ON	Incline Belt OFF	2496
			2459			2478	Belly Belt ON	Belly Belt OFF	2497
			2460	W	B	2479	Incline Raise	Incline Lower	2498
JACK UP/LF		JACK DN/LF	2461	W	B	2480	Incline Left	Incline Right	2499
JACK UP/RT		JACK DN/RT	2462	START	PTO ENGAGE/ DISENGAGE	2481	Lights ON	Lights OFF	2500

Tarp Open	Tarp Close	2501	OS BAR OUT	OS BAR IN	2520			2539
CHOKE OPEN	CHOKE CLOSE	2502	NS BAR OUT	NS BAR IN	2521			2540
WHEEL LIFT UP	WHEEL LIFT DOWN	2503	FREE SPOOL 1	FREE SPOOL 2	2522			2541
FRONT LH LOWER	FRONT LH RAISE	2504	Silo 1 Auf	Silo 1 Zu	2523	N/S WINCH OUT	O/S WINCH OUT	2542
FRONT RH LOWER	FRONT RH RAISE	2505	Silo 2 Auf	Silo 2 Zu	2524	N/S WINCH IN	O/S WINCH IN	2543
REAR LH LOWER	REAR LH RAISE	2506	Silo 3 Auf	Silo 3 Zu	2525	BOTH WINCH IN	BOTH WINCH OUT	2544
REAR RH LOWER	REAR RH RAISE	2507	Winch IN	Winch OUT	2526	WINCH IN	WINCH OUT	2545
LOWER MODULE	RAISE MODULE	2508	Steer LOCK	Steer UNLOCK	2527	WORK LIGHT	SCENE LIGHT	2546
DEADMAN	DEADMAN	2509	TRAVEL LEFT	TRAVEL RIGHT	2528	BIN 1	BIN 2	2547
JETTER ON	JETTER OFF	2510	TANK FEED	TANK REV	2529	BIN 3	BIN 4	2548
BACK PUMP ON	BACK PUMP OFF	2511	SCROLLS ON	SCROLLS REV	2530	CONV START	CONV STOP	2549
START CONVEYOR	STOP CONVEYOR	2512	DE-STONE ON	DE-STONE REV	2531	VIB		2550
MANUAL	AUTO	2513	MAGIC CARPET ON	MAGIC CARPET REV	2532	DSF DOWN	DSF UP	2551
FORWARD	REVERSE	2514	TURBINE START	TURBINE STOP	2533	PSF DOWN	PSF UP	2552
FEEDER SPEED +	FEEDER SPEED -	2515	FRONT LEFT FREE	FRONT LEFT HOLD	2534	DSR DOWN	DSR UP	2553
EJECTOR RAM IN	EJECTOR RAM OUT	2516	FRONT RIGHT FREE	FRONT RIGHT HOLD	2535	PSR DOWN	PSR UP	2554
1	2	2517	BACK LEFT FREE	BACK LEFT HOLD	2536	DS SIDE DOWN	DS SIDE UP	2555
		2518	BACK RIGHT FREE	BACK RIGHT HOLD	2537	PS SIDE DOWN	PS SIDE UP	2556
		2519	FREE ALL		2538	 Bremsen auf	 Bremsen auf	2557

			2558				2577	JACK UP/LF		JACK DN/LF	2596
H3		H3	2559	BED DOWN		BED UP	2578	JACK UP/RT		JACK DN/RT	2597
H4		H4	2560	SLIDE DOWN		SLIDE UP	2579	FRONT WORK LIGHTS ON/OFF		FRONT STROBE ON/OFF	2598
ÖI L		ÖI L	2561	CRADLE DOWN		CRADLE UP	2580	LEFT WORK LIGHTS ON/OFF		LEFT STROBE ON/OFF	2599
ÖI R		ÖI R	2562	↓ O/S Jack		↑ O/S Jack	2581	RIGHT WORK LIGHTS ON/OFF		RIGHT STROBE ON/OFF	2600
H1		H1	2563	LIFT UP		LIFT DOWN	2582	REAR WORK LIGHTS ON/OFF		REAR STROBE ON/OFF	2601
H2		H2	2564	WINCH IN		WINCH OUT	2583				2602
		NOT	2565	CRUSHER START		CRUSHER STOP	2584	Engine START		Engine STOP	2603
			2566	FWD		STOP	2585	Winch IN		Winch OUT	2604
AUGER ON OFF		HAMMER ON OFF	2567	REV		STOP	2586	FEED ON OFF		FEED REV	2605
		THRITTLE	2568	OUT			2587	FEED LIFT		FEED DOWN	2606
BLOWER ON/OFF		JETTER ON/OFF	2569				2588	SPOUT ←		SPOUT →	2607
BOOM IN		BOOM OUT	2570	VIBRATE ON/OFF		HORN	2589	SPOUT IN		SPOUT OUT	2608
BOOM SWING D.S		BOOM SWING P.S	2571	↑↑ FWD		↓↓ REV	2590				2609
DRU WINCH FREESPOOL		BED WINCH FREESPOOL	2572	2x SPEED			2591				2610
BED IN WINCH		BED OUT WINCH	2573	N/S RAMP DOWN		N/S RAMP UP	2592				2611
IN		IN	2574	O/S RAMP DOWN		O/S RAMP UP	2593	FREE SPOOL			2612
OUT		OUT	2575	N/S RAMP OUT		N/S RAMP IN	2594	CLAMP		CLAMP	2613
			2576	O/S RAMP OUT		O/S RAMP IN	2595	ROTATE		SLIDE	2614

SAW	ACTIVATE	2615	STOP	GO	2634	PUMP ON/OFF	REEL IN	2653
BOW THRUSTER PORT	STBD. THRUSTER	2616	PLATFORM ← REVERSE	PLATFORM → FORWARD	2635	REEL IN	REEL OUT	2654
AHEAD	ASTERN	2617	PLATFORM ↓ TILT DOWN	PLATFORM ↑ TILT UP	2636	JET ON	JET OFF	2655
STERN THRUSTER	STBD. THRUSTER	2618	RIGHT 'H' STABILIZER ↓ DOWN	RIGHT 'H' STABILIZER ↑ UP	2637	VACUUM PUMP ON	VACUUM PUMP OFF	2656
N/S SIDE BARS OUT	N/S SIDE BARS IN	2619	LEFT 'H' STABILIZER ↓ DOWN	LEFT 'H' STABILIZER ↑ UP	2638	TANK VACUUM	TANK PRESSURE	2657
O/S SIDE BARS OUT	O/S SIDE BARS IN	2620	SECOND CAR LIFT ↓ DOWN	SECOND CAR LIFT ↑ UP	2639	GATE VALVE OPEN	GATE VALVE CLOSE	2658
T1/T6	T1/T6	2621	SECOND CAR LIFT ← REVERSE	SECOND CAR LIFT → FORWARD	2640	RIGHT UP	RIGHT DOWN	2659
T1/T6	T1/T6	2622	HYDRAULIC WINCH ← REVERSE	HYDRAULIC WINCH → FORWARD	2641	LEFT UP	LEFT DOWN	2660
T2	T2	2623	LEFT 'H' STABILIZER ↑ UP	RIGHT 'H' STABILIZER ↑ UP	2642	TOWER UP	TOWER DOWN	2661
T2	T2	2624	LEFT 'H' STABILIZER ↓ DOWN	RIGHT 'H' STABILIZER ↓ DOWN	2643	STEER LEFT	STEER RIGHT	2662
T3	T3	2625	BEDROOM IN	BEDROOM OUT	2644	AUX 1	AUX 2	2663
T3	T3	2626	KITCHEN IN	KITCHEN OUT	2645	⤵	Dead man	2664
T4	T4	2627	RAMP ⬇	RAMP ⬆	2646	⤴	Dead man	2665
T4	T4	2628	POD CLOSE	POD OPEN	2647	MACHINE OFF	HORN	2666
T5	T5	2629	FLOOR UP	FLOOR DOWN	2648	⬆ PROP FWD	⬇ PROP REV	2667
T5	T5	2630	YOKE OUT	YOKE IN	2649	⬆ VIB (L)	⬆ VIB (R)	2668
M-HOSIT UP	M-HOIST DOWN	2631	SQUEEZE OUT	SQUEEZE IN	2650	⬇ VIB (L)	⬇ VIB (R)	2669
FRONT [SUPPORT] LEG DOWN	REAR [SUPPORT] LEG DOWN	2632	TIP DOWN	TIP UP	2651	VIB L ON/OFF	VIB R ON/OFF	2670
FRONT [SUPPORT] LEG UP	REAR [SUPPORT] LEG UP	2633	DOOR OPEN	DOOR SHUT	2652	BLOWN ON/OFF	GAS ON/OFF	2671

 BRNR (L)	 BRNR (R)	2672	AXLE UP/DOWN	AUX	2691	Boom IN	Boom OUT	2710
 BRNR (L)	 BRNR (R)	2673	FWD	REV	2692	ON BLOWER OFF	ON WATER OFF	2711
 CART (L)	 CART (R)	2674	ROTATE 	ROTATE 	2693	BOOM LEFT	BOOM RIGHT	2712
 CART (L)	 CART (R)	2675	 UP	 DOWN	2694	BOOM LIFT	BOOM LOWER	2713
WHEEL UP	WHEEL DOWN	2676	 EXT	 EXT	2695	BOOM OPEN	BOOM CLOSE	2714
RIGHT WING UP	RIGHT WING DOWN	2677	 BASKET	 BASKET	2696	BLOWER JETTER	DEADMAN	2715
LEFT WING UP	LEFT WING DOWN	2678			2697	FEEDER START	FEEDER FASTER	2716
CLAMP IN	CLAMP OUT	2679			2698	FEEDER STOP	FEEDER SLOWER	2717
ROTATE LEFT	ROTATE RIGHT	2680			2699	STEP UP	STEP DOWN	2718
SAW IN	SAW OUT	2681	 UNLOCK	 LOCK	2700	MAIN BOOM DOWN	MAIN BOOM UP	2719
Klappe 4	Klappe 8	2682		AUX	2701	KICK BOOM DOWN	KICK BOOM UP	2720
Klappe 3	Klappe 7	2683	SLIDER	SLIDER	2702	UNDER LIFT OUT	UNDER LIFT IN	2721
Klappe 2	Klappe 6	2684	LIFT	LIFT	2703	POWER TILT DOWN	POWER TILT UP	2722
Klappe 1	Klappe 5	2685	CHAIN	CHAIN	2704	WINCH OUT	WINCH IN	2723
Anlage EIN	Anlage AUS	2686	Conveyor ON/OFF		2705	TILT OUT	TILT IN	2724
PORT INSIDE WINCH IN	PORT INSIDE WINCH OUT	2687	Steer LEFT	Steer RIGHT	2706	BOOM DOWN	BOOM UP	2725
PORT OUTSIDE WINCH IN	PORT OUTSIDE WINCH OUT	2688	Drive FWD	Drive REV	2707	AUTO LEVEL		2726
STBD INSIDE WINCH IN	STBD INSIDE WINCH OUT	2689	Foot DOWN	Foot UP	2708	PS SIDE UP	PS SIDE DOWN	2727
STBD OUTSIDE WINCH IN	STBD OUTSIDE WINCH OUT	2690	Tilt IN	Tilt OUT	2709	DS SIDE UP	DS SIDE DOWN	2728

		2729			2748			2767
		2730	N/S SIDE OUT	N/S SIDE IN	2749	BED	WINCH	2768
		2731	O/S SIDE OUT	O/S SIDE IN	2750	Split LEFT	Split RIGHT	2769
FREE SPOOL FRONT	FREE SPOOL REAR	2732	LIGHT	RESET	2751	Scoop UP	Scoop DOWN	2770
LEVEL		2733	LOCK FRONT AXLE	WORKING LIGHTS	2752	Head LOCK	Head UNLOCK	2771
WINCH IN	WINCH OUT							
2 UP	2 DOWN	2734	REEL IN	REEL OUT	2753	Slide Door OPEN	Slide Door CLOSED	2772
8 IN	8 OUT							
3 UP	3 DOWN	2735	BELT ON / OFF	VIBRATE ON / OFF	2754	Alley IN	Alley OUT	2773
9 IN	9 OUT							
4 UP	4 DOWN	2736	20 MM BIN	SAND BIN	2755	Rear Doors OPEN	Rear Doors CLOSED	2774
10 UP	10 DOWN							
5 UP	5 DOWN	2737	10 MM BIN	ROTATE CHUTE	2756	Forcing Gate Open	Forcing Gate CLOSED	2775
11 UP	11 DOWN							
6 UP	6 DOWN	2738	BRAKE	BRAKE	2757	BIN #5		2776
12 UP	12 DOWN							
7 UP	7 DOWN	2739			2758	ENTRY BARRIER LEFT OPEN	ENTRY BARRIER RIGHT OPEN	2777
ROOF UP	ROOF DOWN							
13 IN	13 OUT	2740			2759	ENTRY BARRIER LEFT CLOSE	ENTRY BARRIER RIGHT CLOSE	2778
	 Bremsse auf	2741			2760	EXIT BARRIER LEFT OPEN	EXIT BARRIER RIGHT OPEN	2779
		2742			2761	EXIT BARRIER LEFT CLOSE	EXIT BARRIER RIGHT CLOSE	2780
		2743			2762	ENTRY BARRIER OPEN	EXIT BARRIER OPEN	2781
Winch IN	Winch OUT	2744			2763	ENTRY BARRIER CLOSE	EXIT BARRIER CLOSE	2782
Steer LOCK	Steer UNLOCK	2745			2764	S1	S2	2783
Steer LEFT	Steer RIGHT	2746			2765	S3	4/1	2784
Engine CHOKE	Quad FLASHERS	2747			2766	7/1	8/2	2785

9/1	9/2	2786	SP WINCH IN BED WINCH RELEASE	SP WINCH OUT	2805	Tor 2 ↑	Tor 2 ↓	2824
10/1	10/2	2787	SP RIGHT LEG UP	SP RIGHT LEG DOWN	2806	Tor 3 ↑	Tor 3 ↓	2825
11/2	13/1	2788	SP LEFT LEG UP	SP LEFT LEG DOWN	2807	Tor 4 ↑	Tor 4 ↓	2826
14/1	14/2	2789	BED IN	BED OUT	2808	Tor 5 ↑	Tor 5 ↓	2827
15/1	15/2	2790	BED UP	BED DOWN	2809	OPEN 1	CLOSE 1	2828
16/1	16/3	2791	BED WINCH IN	BED WINCH OUT	2810	OPEN 2	CLOSE 2	2829
22/1	23/1	2792	CLAW OPEN	CLAW CLOSE	2811	OPEN 3	CLOSE 3	2830
BODY ON	BODY OFF	2793	RELEASE SP WINCH		2812	START	+ SPEED	2831
FINES DRUM ON/OFF	FEEDER ON/OFF	2794	CW	CCW	2813	STOP	- SPEED	2832
AUGER ON	CONVEYOR ON	2795	DSF TRAILER	DSF TRAILER	2814	N/S/F LEG UP	O/S/F LEG UP	2833
AUGER UP	CHUTE UP	2796	PSF TRAILER	PSF TRAILER	2815	N/S/F LEG DOWN	O/S/F LEG DOWN	2834
AUGER DOWN	CHUTE DOWN	2797	DSR TRAILER	DSR TRAILER	2816	N/S/R LEG UP	O/F/R LEG UP	2835
SLEW LEFT	SLEW RIGHT	2798	PSR TRAILER	PSR TRAILER	2817	N/S/R LEG DOWN	O/S/R LEG DOWN	2836
SAND VIBRATOR	STONE VIBRATOR	2799	DS FLOOR	DS FLOOR	2818	N/S POD IN	O/S POD IN	2837
CEMENT VIBRATOR	GATE VIBRATOR	2800	PS FLOOR	PS FLOOR	2819	N/S POD OUT	O/S POD OUT	2838
THROTTLE	PTO	2801	DS FLAP	DS FLAP	2820	REAR MOULD UP	AUTO LEVEL	2839
ENGINE START	ENGINE STOP	2802	PS FLAP	PS FLAP	2821	REAR MOULD DOWN		2840
NI REEL HOSE	OUT REEL HOSE	2803		ACTIVE	2822			2841
NI ROPE REEL	OUT ROPE REEL	2804	Tor 1 ↑	Tor 1 ↓	2823			2842

		2843	Starten	Reserve	2862	O/S WINCH FRONT UP	O/S WINCH FRONT DOWN	2881
		2844	FRONT SUPPORT LEG DOWN	FRONT SUPPORT LEG UP	2863	N/S SLIDER BACK IN	N/S SLIDER BACK OUT	2882
N/S RAMP UP	N/S RAMP DOWN	2845	REAR SUPPORT LEG DOWN	REAR SUPPORT LEG UP	2864	N/S SLIDER FRONT IN	N/S SLIDER FRONT OUT	2883
O/S RAMP UP	O/S RAMP DOWN	2846			2865	O/S SLIDER BACK IN	O/S SLIDER BACK OUT	2884
N/S RAMP IN	N/S RAMP OUT	2847	HI	HORN	2866	O/S SLIDER FRONT IN	O/S SLIDER FRONT OUT	2885
O/S RAMP IN	O/S RAMP OUT	2848	BIN 3	BIN 4	2867	STEERING LEFT	STEERING RIGHT	2886
S1		2849	10 MM BIN 5	0 - 4 GRITSAND BIN 6	2868	ARMS CLOSE	ARMS OPEN	2887
S2		2850	Vor	Vor	2869	N/S RAMP UP	N/S RAMP DOWN	2888
S3	ROOF	2851	Zurück	Zurück	2870	O/S RAMP UP	O/S RAMP DOWN	2889
S4	DOOR	2852			2871	N/S STEADY LEG UP	N/S STEADY LEG DOWN	2890
SLOW	FAST	2853			2872	O/S STEADY LEG UP	O/S STEADY LEG DOWN	2891
CARRIER WINCH 1 IN	CARRIER WINCH 1 OUT	2854			2873	N/S RAMP IN	N/S RAMP OUT	2892
CARRIER WINCH 2 IN	CARRIER WINCH 2 OUT	2855			2874	O/S RAMP IN	O/S RAMP OUT	2893
TOP DECK TILT UP	TOP DECK TILT DOWN	2856			2875			2894
AUTOGRIP OPEN	AUTOGRIP CLOSED	2857			2876			2895
Zündung O/I	Hydraulik O/I	2858			2877	FRONT AND REAR WINCH "IN"	FRONT AND REAR WINCH "OUT"	2896
Zapfwelle O/I	Absaugung O/I	2859	N/S WINCH BACK UP	N/S WINCH BACK DOWN	2878			2897
Gas -	Gas +	2860	N/S WINCH FRONT UP	N/S WINCH FRONT DOWN	2879	AIR FRONT	AIR REAR	2898
		2861	O/S WINCH BACK UP	O/S WINCH BACK DOWN	2880			2899

			2900	STIFF LEG RIGHT UP			2918		2936
			2901	STIFF LEG LEFT UP			2919	DEADMAN SWITCH	2937
			2902	CLAW OPEN			2920	 UP	2938
			2903	AIR RELEASE			2921	 SLOPE	2939
			2904	Beacon		Rear Message	2922	 CONVEYOR	2940
		BRAKE	2905	Front Light Bar		Rear Work Lights	2923	 SCREED	2941
			2906	MID FLASH UP		MID FLASH DOWN	2924	 AUX	2942
FORWARD/ LEFT OUT 1		TOP UP/ LEFT IN 2	2907	TOP FLASH UP		TOP FLASH DOWN	2925	 TONGUE RET	2943
REVERSE/ RIGHT IN 3		TOP DOWN/ RIGHT OUT 4	2908	PTO 1		PTO 2	2926	 AXLE DOWN	2944
SHIFT 5		AUTO/ MANUAL 6	2909	STROBE		WORK LIGHTS	2927	 JACK UP	2945
WINCH STOP		WINCH FWD	2910	SUCTION VALVE		AUX 1	2928	SPEED 1	PAY OUT
		WINCH REV	2911	AUX 2		AUX 3	2929	SPEED 2	PAY IN
			2912				2930	1	2
			2913	 N/S POD OUT		 N/S POD IN	2931	3	STOP
			2914	 O/S POD OUT		 O/S POD IN	2932	1	2
			2915	CENTRE ISLAND 		CENTRE ISLAND 	2933	3	STOP
			2916	 N/S FLOOR RAM UP		 N/S FLOOR RAM DOWN	2934	1	2
PODS OUT		PODS IN	2917	 O/S FLOOR RAM UP		 O/S FLOOR RAM DOWN	2935	3	STOP

1		2	2954	INWARD		OUTWARD	2973	Spinner UP		Spinner DOWN	2992
3		STOP	2955	START		HORN	2974	1 EXTEND RAMP		1 DECK RAISE	2993
BACK BAR DOWN		BACK BAR UP	2956	TILT FORWARD		TILT BACKWARD	2975	2 DECK UNLOCK		2 DECK LOCK	2994
STIRER FWD		STIRER REV	2957	TILT LEFT		TILT RIGHT	2976	3 DECK RAISE		3 DECK LOWER	2995
HOOVER FWD		HOOVER REV	2958	BLADE CLAMP OPEN		BLADE CLAMP CLOSED	2977	4 DECK LOWER		4 RETRACT RAMP	2996
AUGER UP		AUGER DOWN	2959	PRESSURE PADS UNLOCKED		PRESSURE PADS LOCKED	2978	Table UP/DOWN		Vibration ON/OFF	2997
AUGER LEFT		AUGER RIGHT	2960				2979	Vibration Frequency ▲		Vibration Frequency ▼	2998
AUGER FWD		AUGER REV	2961				2980	Impulse ON/OFF		Boost Mode	2999
CLUTCH ON/OFF			2962				2981			FREE SPOOL	3000
JETTING PUMP		VAC PUMP	2963				2982	BIN 5		BIN 6	3001
REEL 			2964	BIN 3			2983	BACK IN		BACK OUT	3002
		START STOP	2965	D1		P1	2984	START		PTO	3003
GLOW PLUG		START	2966	UP		DN	2985	VAC Breaker		Water Pump On	3004
SWING LEFT		SWING RIGHT	2967	D2		P2	2986	Engine Emergency Stop		AUX 1	3005
BRUSH ON/OFF		SPRINKLER ON/OFF	2968	D3		P30	2987				3006
AUX			2969	Conditioner STOP		Conditioner START	2988				3007
BLINKING LIGHTS		WORKING LIGHTS	2970	WINCH STOP		WINCH FWD	2989				3008
TRANSFER START		FEED CONV START	2971			WINCH REV	2990				3009
TRANSFER STOP		FEED CONV STOP	2972				2991				3010

		3011	5 UP	5 DOWN	3030	Schnell	Langsam	3049
		3012	6 UP	6 DOWN	3031			3050
		3013	FEEDER OFF	FEEDER ON	3032			3051
Inlet OPEN	Inlet CLOSE	3014	L↑	R↑	3033	TRACKS EXTEND	TRACKS RETRACT	3052
Outlet OPEN	Outlet CLOSE	3015	L↓	R↓	3034	F N/S LEG UP	F N/S LEG DOWN	3053
Vent OPEN	Vent CLOSE	3016	TILT UP	ARM UP	3035	F O/S LEG UP	F O/S LEG DOWN	3054
Vacuum TANK	Pressure TANK	3017	TILT DOWN	ARM DOWN	3036	R N/S LEG UP	R N/S LEG DOWN	3055
Reel LEFT	Reel RIGHT	3018	WINCH IN	WINCH OUT	3037	R O/S LEG UP	R O/S LEG DOWN	3056
Water ON	Water OFF	3019	SHIFT LEFT	SHIFT RIGHT	3038	MAIN/TOP BOOM IN	MAIN/TOP BOOM OUT	3057
Jet Low ON	Jet Low OFF	3020	HIGH SPEED	ARM SLOW	3039	CYLINDER OPEN	CYLINDER CLOSE	3058
Jet High ON	Jet High OFF	3021	FAST	FAST	3040	DEADMAN		3059
Auf Stop	Zu Stop	3022	OSMOSE	BASEN-WASSER	3041	3050 GATE 3 CLOSE	3050 GATE 3 OPEN	3060
UNDERLIFT FOLD	UNDERLIFT UNFOLD	3023	DESINFektion		3042	3050 GATE 2 CLOSE	3050 GATE 2 OPEN	3061
UNDERLIFT IN	UNDERLIFT OUT	3024	KICK IN	KICK OUT	3043	DIP OUT	DIP IN	3062
ALL UP	ALL DOWN	3025	R GATE OPEN	R GATE CLOSED	3044	3050 GATE 1 CLOSE	3050 GATE 1 OPEN	3063
1 UP	1 DOWN	3026	L GATE OPEN	L GATE CLOSED	3045			3064
2 UP	2 DOWN	3027			3046			3065
3 UP	3 DOWN	3028			3047			3066
4 UP	4 DOWN	3029	Auf	Ab	3048			3067

LEGS UP	LEGS DOWN	3068	LHS MID JACK UP	LHS MID JACK DOWN	3087			3106
VIBRATOR 1	VIBRATOR 2	3069	HOPPER UP	HOPPER DOWN	3088			3107
		3070			3089			3108
		3071			3090	LMDI	CLEAR FUNCTION	3109
BOOM SWING LEFT	BOOM SWING RIGHT	3072			3091	BOOT OPEN	BOOT CLOSE	3110
PARKING BREAK	HORN	3073			3092	RAMP DOWN	RAMP UP	3111
LIGHTS 1	LIGHTS 2	3074			3093	VEHICLE DOWN	VEHICLE UP	3112
LIGHTS 3	LIGHTS 4	3075	FOLD UNDER UP	FOLD UNDER DOWN	3094	RI	RO	3113
RH REAR FLOOR UP	RH REAR FLOOR DOWN	3076	H-LOCK (LOCK)	H-LOCK (UNLOCK)	3095	E	W	3114
LH REAR FLOOR UP	LH REAR FLOOR DOWN	3077	AUTO OPEN	AUTO CLOSE	3096	VC	VUC	3115
RH CENTRE FLOOR UP	RH CENTRE FLOOR DOWN	3078	MANUAL OPEN	MANUAL CLOSE	3097	HC	HUC	3116
LH CENTRE FLOOR UP	LH CENTRE FLOOR DOWN	3079	JIB UP	JIB DOWN	3098	CL	UCL	3117
FRONT FLOOR UP	FRONT FLOOR DOWN	3080	DUST ON	DUST OFF	3099	OPN	CLS	3118
CLAMP OUT	CLAMP IN	3081			3100	U	D	3119
BOTH MAIN UP	BOTH MAIN DOWN	3082	Rüttlung EIN-AUS	Rüttlung EIN-AUS	3101	VIBRATE		3120
RHS MAIN UP	RHS MAIN DOWN	3083			3102			3121
LHS MAIN UP	LHS MAIN DOWN	3084	ALL UP	ALL DOWN	3103			3122
REAR RAM UP	REAR RAM DOWN	3085	DECK WINCH IN	DECK WINCH OUT	3104			3123
RHS MID JACK UP	RHS MID JACK DOWN	3086	WINCH IN (SIDE PULLER)	WINCH OUT (SIDE PULLER)	3105			3124


LEFT WINCH IN	LEFT WINCH OUT	3125	ENGINE ON	ENGINE OFF	3144	MYJKA DO GÓRY	MYJKA OPUSZCZONY	3163
RIGHT WINCH IN	RIGHT WINCH OUT	3126	IDLE UP	IDLE DOWN	3145	MYJKA W LEWO	MYJKA W PRAWO	3164
1	B1	3127	BELT ON	BELT OFF	3146	FRAM	FRAM	3165
2	B2	3128	JACK DOWN	JACK UP	3147	BAK	BAK	3166
3	M1	3129	ENGINE STOP	RPM ON	3148	FRAM	FRAM	3167
4	M2	3130	RAMP	RAMP	3149	FRAM	FRAM	3168
5	FTSM	3131	RAMP	RAMP	3150	BAK	BAK	3169
6	M1	3132	RAMP	RAMP	3151	BAK	BAK	3170
7	M2	3133			3152			3171
M1	B1	3134			3153			3172
M2	B2	3135	DECK	DECK	3154			3173
FTSM	OUT	3136	ROLKA WŁOŻONA	ROLKA WYJĘTA	3155	4		3174
RESET		3137	STRUMIEŃ WŁĄCZONY	STRUMIEŃ WYŁĄCZONY	3156	DECK DOWN	DECK UP	3175
RAMP	RAMP	3138	POMPA PRÓŻNIOWA WŁĄCZONA	POMPA PRÓŻNIOWA WYŁĄCZONA	3157	BLOWER ON OFF	WATER ON OFF	3176
RAMP	RAMP	3139	PRÓŻNIA W ZBIORNIKU	CIŚNIENIE W ZBIORNIKU	3158	SLEW LEFT	SLEW RIGHT	3177
		3140	KURZ WŁĄCZONY	KURZ WYŁĄCZONY	3159	BOOM UP	BOOM DOWN	3178
		3141	ZAWÓR ZASUWOWY OTWARTY	ZAMKNIĘTY ZAWÓR ZASUWOWY	3160	BOOM IN	BOOM OUT	3179
		3142	PISTOLET DESZCZOWY W LEWO	PISTOLET DESZCZOWY W PRAWO	3161	BOOM OPEN	BOOM CLOSE	3180
		3143	PISTOLET DESZCZOWY PODNIESIONY	PISTOLET DESZCZOWY OPUSZCZONY	3162	DOOR OPEN	DOOR CLOSE	3181

TANK	TANK	3182	Deckel Öffnen	Deckel Schließen	3200			3218
UP	DOWN							
BLOWER	DEAD MAN	3183	Pool Auf	Pool Ab	3201			3219
HI LOW								
Halt	Start	3184	Links An	Rechts An	3202			3220
Free SPOOL	Air DUMP	3185	Links Aus	Rechts Aus	3203		9	3221
ON OFF	ON OFF							
HORN	2 SPEED	3186	Vorne	Hinten	3204	10	11	3222
1↓	1↑	3187	Rundum		3205	14	15	3223
2↓	2↑	3188			3206		FREE	3224
1↓	1↑	3189	1↓	1↑	3207			3225
2↓	2↑	3190			3208	LS	FWD	3226
3↓	3↑	3191	M	M	3209	RS	REV	3227
4↓	4↑	3192	Bumper Out	Bumper In	3210	V	HS	3228
5↓	5↑	3193	Blink Light	Liftaxle	3211	LHS SIDE ROOF OPEN	LHS SIDE ROOF CLOSE	3229
6↓	6↑	3194			3212	RHS SIDE ROOF OPEN	RHS SIDE ROOF CLOSE	3230
Ausl. Zu ↓	Ausl. Auf ↑	3195	AIR RELEASE	AIR RELEASE	3213	REAR DOOR OPEN	REAR DOOR CLOSE	3231
Stufe 1	Stufe 2	3196	INCLINE CONVEYOR STOP	INCLINE CONVEYOR START	3214	CARGO FLOOR ON OFF		3232
VIBRATOR ON	VIBRATOR OFF	3197	FEED CONVEYOR STOP	FEED CONVEYOR START	3215	DOOR LOCK OPEN CLOSE		3233
		3198	W/L UP	W/L DOWN	3216	lad ud	lad ind	3234
Deckel Auf	Deckel Ab	3199	STINGER IN	STINGER OUT	3217	Tip op	Tip ned	3235

		3236	ROOF UP	ROOF DOWN	3254			3272
		3237	DOOR OPEN	DOOR CLOSE	3255			3273
FREE SPOOL ON/OFF	MBS ON/OFF	3238	FRONT NECK UP	FRONT NECK DOWN	3256			3274
BACK GATE CLOSE	BACK GATE OPEN	3239	FRONT SCREW UP	FRONT SCREW DOWN	3257			3275
CONV STOP	CONV START	3240	REAR SCREW UP	REAR SCREW DOWN	3258			3276
		3241	GOOSENECK UP	GOOSENECK DOWN	3259	LEG 1 UP SIGN 1 UP	LEG 1 DOWN SIGN 1 DOWN	3277
2nd CAR IN	2nd CAR OUT	3242	BELLY DECK UP	BELLY DECK DOWN	3260	LEG 2 UP SIGN 2 UP	LEG 2 DOWN SIGN 2 DOWN	3278
2nd CAR UP	2nd CAR DOWN	3243	FRONT WINCH IN	FRONT WINCH OUT	3261	LEG 3 UP SIGN 3 UP	LEG 3 DOWN SIGN 3 DOWN	3279
REEL IN	REEL OUT	3244	REAR WINCH IN	REAR WINCH OUT	3262	LEG 4 UP SIGN 4 UP	LEG 4 DOWN SIGN 4 DOWN	3280
JET OFF	JET ON	3245	TAIL LIFT TILT		3263	CANOPY 1 UP	CANOPY 1 DOWN	3281
VACUUM PUMP OFF	VACUUM PUMP ON	3246			3264	CANOPY 2 UP	CANOPY 2 DOWN	3282
TANK VACUUM	TANK PRESSURE	3247	ALL JACKS UP	ALL JACKS DOWN	3265	CANOPY 3 UP	CANOPY 3 DOWN	3283
DUST OFF	DUST ON	3248		Pumpe	3266	CANOPY 4 UP	CANOPY 4 DOWN	3284
GATE VALVE CLOSE	GATE VALVE OPEN	3249	LH FRONT OUTRIGGER UP	LH FRONT OUTRIGGER DOWN	3267	YOKE OPEN	YOKE CLOSE	3285
RAIN GUN LEFT	RAIN GUN RIGHT	3250	LH REAR OUTRIGGER UP	LH REAR OUTRIGGER DOWN	3268	DOOR OPEN	DOOR CLOSE	3286
RAIN GUN UP	RAIN GUN DOWN	3251	FRONT GATE OPEN	FRONT GATE CLOSED	3269	RELEASE	SQUEEZE	3287
WASH BAR UP	WASH BAR DOWN	3252	BACK GATE OPEN	BACK GATE CLOSED	3270	ROLL DOWN	ROLL OVER	3288
WASH BAR LEFT	WASH BAR RIGHT	3253			3271	BACK BAR UP	BACK BAR DOWN	3289

		3290			3309			3328
Pumpe An		3291			3310			3329
BIN #5		3292			3311			3330
		3293			3312			3331
		3294			3313			3332
		3295			3314			3333
		3296			3315			3334
		3297			3316			3335
		3298			3317			3336
Vor	Zurück	3299			3318			3337
		3300			3319			3338
		3301			3320			3339
		3302			3321			3340
		3303			3322			3341
STOP	COND START	3304			3323			3342
		3305			3324			3343
		3306			3325			3344
		3307			3326			3345
		3308			3327			3346

UNDERLIFT IN	UNDERLIFT OUT	3347	FLOOR 1 ON	FLOOR 2 ON	3366			3385
BOOM UP	BOOM DOWN	3348	FLOOR 1 OFF	FLOOR 2 OFF	3367			3386
ARMS CLOSE	ARMS OPEN	3349	Tor 3	Tor 12	3368			3387
L/R WINCH CLUTCH SAFETY	AUXILIARY	3350	Tor 15	Tor 16	3369			3388
STINGER IN	STINGER OUT	3351	Tor 17	Tor 20	3370			3389
		3352	N4 Tor 01		3371			3390
		3353			3372			3391
		3354			3373			3392
SECOND CAR LIFT (IN)	SECOND CAR LIFT (OUT)	3355			3374			3393
BIG WINCH IN	BIG WINCH OUT	3356			3375			3394
SMALL WINCH IN	SMALL WINCH OUT	3357			3376			3395
SPEC IN WHEEL LIFT	SPEC OUT WHEEL LIFT	3358			3377			3396
SPEC UP WHEEL LIFT	SPEC DOWN WHEEL LIFT	3359			3378			3397
#9 RH LEG UP	#9 RH LEG DOWN	3360			3379			3398
#9 LH LEG UP	#9 LH LEG DOWN	3361			3380			3399
BOOM UP	BOOM DOWN	3362			3381			3400
BOOM EXTEND	BOOM RETRACT	3363			3382			3401
POWER PACK START	POWER PACK STOP	3364			3383			3402
FEEDER STOP/START	AUTO STOP/START	3365			3384			3403

CHASSIS 			3404	TOP DECK UP	TOP DECK DOWN	3423	WING AXLE UP	WING AXLE DOWN	3442
PLATEAU 			3405	CENTRE ISLAND 		3424	RADIAL LEFT	RADIAL RIGHT	3443
			3406	RUNWAY LIGHTS		3425			3444
			3407	SCOOP UP	SCOOP DOWN	3426	Conveyor START	Conveyor STOP	3445
			3408	HEAD LOCK	HEAD UNLOCK	3427	Radial LEFT	Radial RIGHT	3446
Water Pump ON	AUX 1		3409	SQUEEZE IN	SQUEEZE OUT	3428	KICK IN	KICK OUT	3447
AUX 2	AC BREAKER		3410	DOOR OPEN	DOOR CLOSED	3429	FRONT LEFT 	FRONT LEFT 	3448
AUX 3	ENGINE EMERGENCY STOP		3411	Shelter West Rück	Shelter West Vor	3430	FRONT RIGHT 	FRONT RIGHT 	3449
AUX 4	AUX 5		3412	Shelter Ost Rück	Shelter Ost Vor	3431			3450
5			3413	Shelter West/Ost Rück	Shelter West/Ost Vor	3432			3451
D STIFF LEG UP	D STIFF LEG DOWN		3414			3433			3452
P STIFF LEG UP	P STIFF LEG DOWN		3415			3434	BACK BAR CLOSE	BACK BAR OPEN	3453
S/P WINCH IN	S/P WINCH OUT		3416			3435	LIFT UP	LIFT DOWN	3454
 All Winches IN	 All Winches OUT		3417			3436	BELLY BAND UP	BELLY BAND DOWN	3455
			3418	SLOW	FAST	3437			3456
LEFT 	LEFT 		3419	CONVEYOR ON OFF		3438			3457
RIGHT 	RIGHT 		3420	LEFT TRACK FORWARD	RIGHT TRACK FORWARD	3439			3458
WINCH ON	WINCH OFF		3421	LEFT TRACK REVERSE	RIGHT TRACK REVERSE	3440			3459
BODY UP	BODY DOWN		3422	CONVEYOR UP	CONVEYOR UP	3441			3460

RAISE ALL	FLOAT ALL	3461	3507 GATE 2 CLOSE	OPEN GATE 2	3479	IN	OUT	3497
RAISE LEFT SIDE	RAISE RIGHT SIDE	3462	3508 DIP	NI DIP	3480	SIREN	FEEDER	3498
FLOAT LEFT SIDE	FLOAT RIGHT SIDE	3463	3509 GATE 1 CLOSE	OPEN GATE 1	3481	OPEN DOOR 1	CLOSE DOOR 1	3499
LOWER LEFT WING	LOWER RIGHT WING	3464			3482	STOP DOOR 1	OPEN DOOR 2	3500
GROOMING LIGHT	WORK LIGHTS	3465			3483	CLOSE DOOR 2	STOP DOOR 2	3501
RAISE FRONT	LOWER FRONT	3466	RUNWAY LIGHTS		3484	OPEN DOOR 3	CLOSE DOOR 3	3502
RAISE BACK	LOWER BACK	3467			3485	STOP DOOR 3		3503
RAISE LEFT	LOWER LEFT	3468			3486	PTO	WATER PUMP	3504
RAISE RIGHT	LOWER RIGHT	3469			3487	WORK LIGHTS		3505
RAISE ALL	LOWER ALL	3470			3488			3506
		3471			3489			3507
TILT UP	TILT DOWN	3472	PTO	WATER PUMP	3490			3508
FRONT EXTEND	FRONT RETRACT	3473	WORK LIGHTS		3491			3509
REAR EXTEND	REAR RETRACT	3474	BOOM FOLD	BOOM UNFOLD	3492			3510
REAR SHIFT-LEFT	REAR SHIFT-RIGHT	3475	N/S LEG UP	N/S LEG DOWN	3493	Sync ON/OFF	Winch 3 ON/OFF	3511
		3476	O/S LEG UP	O/S LEG DOWN	3494	Winch 3 IN	Winch 3 OUT	3512
		3477			3495	CLOSE BAR BACK	OPEN BAR BACK	3513
3514 GATE 3 CLOSE	OPEN GATE 3	3478	BALE UP	BALE DOWN	3496	CLOSE HEAD GATE	OPEN HEAD GATE	3514

NMOD BAND BELLY		UP BAND BELLY	3515	Door OPEN		Door SHUT	3534	INLET VALVE OPEN		INLET VALVE CLOSE	3553
JACK LEG 1 UP		JACK LEG 1 DOWN	3516	Tank UP		Tank DOWN	3535	KICK DOWN		KICK UP	3554
JACK LEG 2 UP		JACK LEG 2 DOWN	3517				3536				3555
JACK LEG 3 UP		JACK LEG 3 DOWN	3518				3537				3556
JACK LEG 4 UP		JACK LEG 4 DOWN	3519	FLAP 		FLAP 	3538	Left Stabilizer 		Left Stabilizer 	3557
TOOLBOX 1 OUT		TOOLBOX 1 IN	3520	YOKE 		YOKE 	3539	Right Stabilizer 		Right Stabilizer 	3558
TOOLBOX 2 OUT		TOOLBOX 2 IN	3521	T1 		T1 	3540	Main Winch IN 		Main Winch OUT 	3559
NECK DECK UP		NECK DECK DOWN	3522	TURRET ROTATE LEFT		TURRET ROTATE RIGHT	3541				3560
NECK DECK OUT		NECK DECK IN	3523	JIB ROTATE LEFT		JIB ROTATE RIGHT	3542	HOOK UP		HOOK DOWN	3561
MAIN DECK FRONT UP		MAIN DECK FRONT DOWN	3524	TRANSLATION LEFT		TRANSLATION RIGHT	3543	HOOK SLIDE FORWARD		HOOK SLIDE BACKWARDS	3562
MAIN DECK REAR UP		MAIN DECK REAR DOWN	3525				3544	BIN LOCKS LOCK		BIN LOCK UNLOCK	3563
REAR DECK UP		REAR DECK DOWN	3526				3545	BIN DOORS OPEN		BIN DOORS CLOSE	3564
REAR DECK OUT		REAR DECK IN	3527				3546	WALKING FLOOR LOADING		WALKING FLOOR OFF-LOADING	3565
TRAILER EXTEND		TRAILER RETRACT	3528	JET REEL IN		JET REEL OUT	3547	AUGER LOADING		AUGER OFF-LOADING	3566
Gerni ON OFF		Air Valve ON OFF	3529	SMALL REEL OFF		SMALL REEL ON	3548	ROTARY VALVE LOADING		ROTARY VALVE OFF-LOADING	3567
Jetter ON OFF			3530	SMALL REEL IN		SMALL REEL OUT	3549	BODY UNLOCK		BODY LOCK	3568
Reel IN		Reel OUT	3531	DOOR OPEN/ RAISE BODY		DOOR CLOSE/ LOWER BODY	3550	WINCH IN		WINCH OUT	3569
Jetter Flow UP		Jetter Flow DOWN	3532	DOOR LATCH OPEN		DOOR LATCH CLOSE	3551	BEAMTAIL DOWN		BEAMTAIL UP	3570
			3533	BACK VALVE OPEN		BACK VALVE CLOSE	3552	RAMP DOWN		RAMP UP	3571

HOPPER OPEN	HOPPER CLOSE	3572			3591			3610
NAV LIGHTS	AUX	3573			3592			3611
IN	OUT	3574			3593	BEAM POSITION	SERVICE POSITION	3612
START/ STOP 1	START/ STOP 2	3575	FREE SPOOL 1	FREE SPOOL 2	3594	AUTO STOP/START	FEEDER STOP/START	3613
		3576			3595			3614
		3577	LEFT WINCH IN	LEFT WINCH OUT	3596			3615
		3578	RAISE	LOWER	3597	FORWARD AUTO HOME	TOP UP ARCH UP	3616
		3579	SLIDE ON	SLIDE OFF	3598	REVERSE ROTATE 15	TOP DOWN ARCH DOWN	3617
		3580			3599	Locks	Locks	3618
		3581			3600			3619
		3582			3601			3620
		3583			3602	LEG	SPADE	3621
		3584			3603	LEG	SPADE	3622
		3585	TRIPPER FWD	WINCH FWD	3604			3623
		3586	TRIPPER REV	WINCH REV	3605			3624
		3587	DOOR	ROOF	3606	Gate 1 Open	Gate 1 Close	3625
		3588	P1	P2	3607	Gate 2 Open	Gate 2 Close	3626
		3589	P3	P4	3608	Gate 3 Open	Gate 3 Close	3627
		3590			3609	Gate 4 Open	Gate 4 Close	3628

Conveyor Raise	Conveyor Lower	3629	PLATFORM ↓ DOWN	PLATFORM ↑ UP	3648	WINCH	WINCH	3667
Conveyor Left	Conveyor Right	3630	WINCH ← IN	WINCH → OUT	3649		CENTER	3668
Belt ON	Belt OFF	3631	GRIZZLY RAISE		3650	LEFT	RIGHT	3669
Tarp Open	Tarp Close	3632	1	1	3651	AUX 1		3670
		3633	Gate 5 Open	Gate 5 Close	3652	HATBOX UP	HATBOX DOWN	3671
STOP	Blend START	3634	Interior Light On	Interior Light Off	3653			3672
BLEND DIRECT	Loadout START	3635	Unload Light On	Unload Light Off	3654	BED	WINCH	3673
Loadout Conveyor STOP	Loadout Conveyor START	3636	Rear Light On	Rear Light Off	3655			3674
Hopper Conveyor STOP	Hopper Conveyor START	3637			3656	UNDERLIFT FOLD UP	UNDERLIFT FOLD DOWN	3675
Cond STOP	Cond START	3638	POWERPACK STOP/START	FEEDER STOP/START	3657	BOOM LIFT UP	BOOM LIFT DOWN	3676
		3639	EXTENSION IN	EXTENSION OUT	3658	UNDERLIFT EXTEND IN	UNDERLIFT EXTEND OUT	3677
FEED BIN STOP	FEED BIN START	3640	A1 Extend B3 Extend	A1 Retract B3 Retract	3659	UNDERLIFT TILT UP	UNDERLIFT TILT DOWN	3678
SPEED UP	SPEED DOWN	3641	A2 Extend C1 Extend	A2 Retract C1 Retract	3660	BOOM EXTEND IN	BOOM EXTEND OUT	3679
RAISE	LOWER	3642	A3 Extend C2 Extend	A3 Retract C2 Retract	3661	WINCH IN	WINCH OUT	3680
FREESPOOL ON/OFF	WINCH LOW/HIGH	3643	A4 Extend C3 Extend	A4 Retract C3 Retract	3662	WINCH IN	WINCH OUT	3681
FOLD DOWN	FOLD UP	3644	A5 Extend D1 Extend	A5 Retract D1 Retract	3663	FRONT WINCH IN	FRONT WINCH OUT	3682
SPEC OUT	SPEC IN	3645	A6 Extend D2 Extend	A6 Retract D2 Retract	3664			3683
LEFT	LEFT	3646	B1 Extend	B1 Retract	3665			3684
RIGHT	RIGHT	3647	B2 Extend	B2 Retract	3666	ENGINE STOP	WATER ON/OFF	3685

VAC PUMP OFF	VAC PUMP ON	3686	LEFT WINCH IN	LEFT WINCH OUT	3705			3724
TURBO FILLER OFF	TURBO FILLER ON	3687	RIGHT WINCH IN	RIGHT WINCH OUT	3706			3725
FILL	EMPTY	3688	Gebläse Drehzahl Minus	Gebläse Drehzahl Plus	3707			3727
ARM RAISE	ARM LOWER	3689	Gebläse AUS	Gebläse EIN	3708			3728
ARM IN	ARM OUT	3690	Gebläse Senken	Gebläse Heben	3709			3729
CONE OPEN	CONE CLOSE	3691	Drehen Links	Drehen Rechts	3710			3730
RGV OPEN	RGV CLOSE	3692	Wasser 1 AUS	Wasser 1 EIN	3711	PUMP I	VACUUM I	3731
		3693	Wasser 2 AUS	Wasser 2 EIN	3712	O/S		3732
EXIT CONVEYOR FORWARD	EXIT CONVEYOR REVERSE	3694	+ Schritte Mulde 2	- Schritte Mulde 2	3713	UP	DOWN	3733
WRAP LINE PAUSE	AUX FUNCTION	3695	→ Schritte Mulde 3	← Schritte Mulde 3	3714	LEFT	RIGHT	3734
AUTOMATIC CYCLE START	CYCLE RESET	3696	+ Bunker Mulde BKKW	- Bunker Mulde BKKW	3715	OPEN	CLOSE	3735
CONVEYOR FORWARD	CONVEYOR REVERSE	3697	Grünes Band	Blaues Band	3716	PUMP ON	PUMP OFF	3736
CONVEYOR ENABLE/DISABLE	WRAPPER HI/LO	3698	STOP		3717	ON OFF		3737
BED	WINCH	3699	↑ 1	↑ 2	3718	RAISE ↑	↓ LOWER	3738
DOOR CLOSE	DOOR OPEN	3700	↓ 1	↓ 2	3719	LEFT BOX EXTEND	LEFT BOX RETRACT	3739
FOLD UP	FOLD DOWN	3701	13		3720	RIGHT BOX EXTEND	RIGHT BOX RETRACT	3740
BOOM UP	BOOM DOWN	3702	14	15	3721	ARM GV OPEN	ARM GV CLOSE	3741
SWING IN	SWING OUT	3703	16		3722	TELE CYL UP	SHOOT CYL UP	3742
EXT IN	EXT OUT	3704	↑ SP	↓ SP	3723	TELE CYL DOWN	SHOOT CYL DOWN	3743

			3798	JETTER ON	JETTER OFF	3817			3836
			3799	REEL ON	REEL OFF	3818			3837
			3800			3819			3838
			3801			3820	UNLOCK PIN	UNLOCK DECK	3839
			3802			3821	CRANK	SPEED	3840
			3803	CCW	CW	3822	AUX 1	AUX 2	3841
			3804	OPEN/ DIS.	SAW/ LG	3823	AUX 3	AUX 4	3842
			3805	CLOSE/ ENGAGE	TILT UP	3824	AUX 5	AUX 6	3843
			3806	START	TILT DOWN	3825	AUX 7	AUX 8	3844
			3807	RUN	FLOAT	3826			3845
			3808	FRONT ROOF UP	FRONT ROOF DOWN	3827			3846
			3809	FRONT LOCKING PINS IN	FRONT LOCKING PINS OUT	3828	UNDER LIFT IN	UNDER LIFT OUT	3847
Z-1	Z-2		3810	FRONT DECK UP	FRONT DECK DOWN	3829	BOOM TILT UP	BOOM TILT DOWN	3848
Z-3	Z-4		3811	REAR ROOF UP	REAR ROOF DOWN	3830	UPPER WINCH IN	UPPER WINCH OUT	3849
Z 1,2	Z 1,2,3		3812	REAR LOCKING PINS IN	REAR LOCKING PINS OUT	3831	LEFT LEG IN	LEFT LEG OUT	3850
Z 1,2,3,4			3813	REAR DECK UP	REAR DECK DOWN	3832	LEFT LEG UP	LEFT LEG DOWN	3851
			3814	ON	OFF	3833	FRONT WINCH IN	FRONT WINCH OUT	3852
			3815	IN	OUT	3834	RIGHT LEG IN	RIGHT LEG OUT	3853
			3816	NEAR WINCH 	FAR WINCH 	3835	RIGHT LEG UP	RIGHT LEG DOWN	3854

LOWER WINCH IN		LOWER WINCH OUT	3855	RHS IN		RHS OUT	3873	SUPPORTS RF UP		SUPPORTS RF DOWN	3891
VAC BRKR		WATER PUMP	3856	LHS IN		LHS OUT	3874	SUPPORTS LR UP		SUPPORTS LR DOWN	3892
RPM INC		RPM DEC	3857	RHS ARM UP		RHS ARM DOWN	3875	SUPPORTS RR UP		SUPPORTS RR DOWN	3893
ENGINE STOP			3858	LHS ARM UP		LHS ARM DOWN	3876	PODIUM L UP		PODIUM L DOWN	3894
N5 Tor 01		N5 Tor 02	3859	ROTATION FORWARD		ROTATION REVERSE	3877	PODIUM R UP		PODIUM L DOWN	3895
			3860	ROTATOR FRAME UP		ROTATOR FRAME DN	3878	BALCONY UP		BALCONY DOWN	3896
			3861	Spare 1a		Spare 1b	3879	FACADE UP		FACADE DOWN	3897
			3862	Spare 2a		Spare 2b	3880	STOP		START	3898
			3863	PLATFORM WINCH IN SECOND WINCH IN		PLATFORM WINCH OUT SECOND WINCH OUT	3881	1		2	3899
AUTO LEVELING		DUMMY	3864	PLATFORM TILT UP		PLATFORM TILT DOWN	3882	3		4	3900
			3865	PLATFORM SLIDE ON		PLATFORM SLIDE OFF	3883	STOP		STOP ALL	3901
Hydraulik EIN		Hydraulik AUS	3866	SCL LIFT UP		SCL LIFT DOWN	3884	FLOOR DOWN		FLOOR UP	3902
FS senken		FS heben	3867	SCL LIFT IN		SCL LIFT OUT	3885	Lights ON		Lights OFF	3903
FS schwenken links		FS schwenken rechts	3868	REAR RAMPS IN		REAR RAMPS OUT	3886	Spray ON		Spray OFF	3904
Schieber AUF		Schieber ZU	3869	AGITATE		LOAD	3887	REVERSE		FORWARD	3905
FS ausfahren		FS einfahren	3870	FLOOR L UP		FLOOR L DOWN	3888	ENABLE			3906
EAST		WEST	3871	FLOOR R UP		FLOOR R DOWN	3889				3907
LIFT		DROP	3872	SUPPORTS LF UP		SUPPORTS LF DOWN	3890				3908

		STOP ALL	3909	LEFT SP WINCH OUT		RIGHT SP WINCH OUT	3928	HITCH UP		HITCH DOWN	3947
N/S FRONT IN N/S POD OUT		N/S FRONT OUT N/S POD IN	3910	LEFT SP WINCH FREESPOOL		RIGHT SP WINCH FREESPOOL	3929	FLOOR ON/OFF			3948
O/S FRONT IN N/S FLOOR UP		O/S FRONT OUT N/S FLOOR DOWN	3911	LEFT SP JACK LEG UP		RIGHT SP JACK LEG UP	3930	T HEAD IN		T HEAD OUT	3949
N/S REAR IN		N/S REAR OUT	3912	LEFT SP JACK LEG DOWN		RIGHT SP JACK LEG DOWN	3931	POWERTILT UP		POWERTILT DOWN	3950
O/S REAR IN		O/S REAR OUT	3913	BED WINCH IN		BED WINCH FREESPOOL	3932	LEFT OUT		LEFT IN	3951
O/S POD OUT		O/S POD IN	3914	BED WINCH OUT		SP WORK LIGHT	3933	RIGHT OUT		RIGHT IN	3952
O/S FLOOR UP		O/S FLOOR DOWN	3915				3934	N/S REAR IN SCREEN COVER UP		N/S REAR OUT SCREEN COVER DOWN	3953
GULL ROOF UP		GULL ROOF DOWN	3916				3935	LEFT WINCH FREESPOOL		RIGHT WINCH FREESPOOL	3954
GULL FLOOR UP		GULL FLOOR DOWN	3917				3936				3955
FRONT POD OUT		FRONT POD IN	3918				3937				3956
DEADMAN		DEADMAN	3919				3938				3957
ELEVATOR FWD		ELEVATOR REV	3920				3939				3958
CHUTE IN		CHUTE OUT	3921	 		 	3940				3959
ROLLER UP		ROLLER DOWN	3922	 		 	3941				3960
FLAP UP		FLAP DOWN	3923	 		 	3942				3961
IN		OUT	3924	 		 	3943				3962
SLACK		SLACK	3925	Front OPEN		Front CLOSE	3944				3963
2ND PUMP		HIGH SPEED	3926	Centre OPEN		Centre CLOSE	3945				3964
LEFT SP WINCH IN		RIGHT SP WINCH IN	3927	Rear OPEN		Rear CLOSE	3946	 Winch 9 IN		 Winch 9 OUT	3965

 Winch 10 IN	 Winch 10 OUT	3966	 ENGINE STOP	 ENGINE START	3985	SIGN 2 UP	SIGN 2 DOWN	4004
MOTOR START	MOTOR STOP	3967	 LOAD SPOOL	 UNLOAD SPOOL	3986	SIGN 3 UP	SIGN 3 DOWN	4005
PTO 1 ON/OFF	PTO 2 ON/OFF	3968	 UNLOAD TARPS	 LOAD TARPS	3987	SIGN 4 UP	SIGN 4 DOWN	4006
MAIN PUMP STOP	MAIN PUMP START	3969		 LIFT	3988	LHF JACK UP LH POD IN	LHF JACK DOWN LH POD OUT	4007
 LIFT DOWN	 LIFT UP	3970		 LIFT	3989	RHF JACK UP LHR FLOOR UP	RHF JACK DOWN LHR FLOOR DOWN	4008
UNDER LIFT IN	UNDER LIFT OUT	3971	DRIVE FORWARD	DRIVE REVERSE	3990	LHR JACK UP LHM FLOOR UP	LHR JACK DOWN LHM FLOOR DOWN	4009
CROSS OVER FRONT WINCH		3972	DRU FREE SPOOL	BED FREE SPOOL	3991	RHR JACK UP LHF FLOOR UP	RHR JACK DOWN LHF FLOOR DOWN	4010
WINCH CLUTCH		3973	FEEDER ON	FEEDER OFF	3992	RH POD IN	RH POD OUT	4011
START	STOP	3974	HIGH	LOW	3993	RH FLOOR UP	RH FLOOR DOWN	4012
Water Pump ON	WORK LIGHTS	3975	LOCK PIN IN	LOCK PIN OUT	3994			4013
Aux 1	VAC BREAKER	3976	DECK DOWN	DECK UP	3995	START CONVEYOR	STOP CONVEYOR	4014
Aux 2	ENGINE EMERGENCY STOP	3977	RAMPS DOWN	RAMPS UP	3996	START VIBRATOR	STOP VIBRATOR	4015
AUX RESET	E/S RESET	3978	N/S RAMP SIDE SHIFT IN	N/S RAMP SIDE SHIFT OUT	3997	PTO ON/OFF	VAC PUMP	4016
START CYCLE	STOP CYCLE	3979	O/S RAMP SIDE SHIFT IN	O/S RAMP SIDE SHIFT OUT	3998	JETTER	REEL	4017
START VIB		3980	LEG 1 UP	LEG 1 DOWN	3999	LIGHTS	AUX	4018
 (OFF)	 (OFF)	3981	LEG 2 UP	LEG 2 DOWN	4000	LOAD DUMP	LOAD CLOSED	4019
 (DOWN)	 (UP)	3982	LEG 3 UP	LEG 3 DOWN	4001	LIFT AXLE UP	LIFT AXLE DOWN	4020
BF-1	BF-2	3983	LEG 4 UP	LEG 4 DOWN	4002	Hydro Pump ON OFF	Air Valve ON OFF	4021
BF-3	BF-4	3984	SIGN 1 UP	SIGN 1 DOWN	4003	Boom RAISE	Boom LOWER	4022

Boom IN	Boom OUT	4023	B3 EXT	B3 RET	4042	REAR LEGS ▼	REAR LEGS ▲	4061
Boom LEFT	Boom RIGHT	4024	A1 EXT C1 EXT	A1 RET C1 RET	4043	SHEET COVER	SHEET UNCOVER	4062
Door OPEN	Door CLOSE	4025	A2 EXT C2 EXT	A2 RET C2 RET	4044	SHEET EXTEND	SHEET RETRACT	4063
Body RAISE	Body LOWER	4026	A3 EXT C3 EXT	A3 RET C3 RET	4045	OVERRIDE TILT DOWN	CHANGE OVER	4064
Jetter ON OFF	Jetter ON Activate	4027	A4 EXT B1 EXT	A4 RET B1 RET	4046	BED FWD	BED BACK	4065
Reel IN	Reel OUT	4028	A5 EXT B2 EXT	A5 RET B2 RET	4047	CLAWS OPEN	CLAWS CLOSE	4066
Jetter Flow INCREASE	Jetter Flow DECREASE	4029	A6 EXT B3 EXT	A6 RET B3 RET	4048	TRUCK LOAD OUT STOP	TRUCK LOAD OUT START	4067
		4030	D1 EXT	D1 RET	4049	CONDITIONER STOP	CONDITIONER START	4068
VAC JET	VAC PUMP	4031	D2 EXT	D2 RET	4050	90" HOPPER CONVEY STOP	90" HOPPER CONVEY START	4069
JETTER	REEL	4032	LHF JACK UP	LHF JACK DOWN	4051	40" HOPPER CONVEY STOP	40" HOPPER CONVEY START	4070
LIGHTS	AUX	4033	RHF JACK UP	RHF JACK DOWN	4052	ALL STOP		4071
A1 EXT T1 EXT	A1 RET T1 RET	4034	LHR JACK UP	LHR JACK DOWN	4053	60" HOPPER CONVEY STOP	60" HOPPER CONVEY START	4072
A2 EXT T2 EXT	A2 RET T2 RET	4035	RHR JACK UP	RHR JACK DOWN	4054	50" HOPPER CONVEY STOP	50" HOPPER CONVEY START	4073
A3 EXT T3 EXT	A3 RET T3 RET	4036	LH POD IN	LH POD OUT	4055	RH POD IN	RH POD OUT	4074
A4 EXT T4 EXT	A4 RET T4 RET	4037	LHR FLOOR UP	LHR FLOOR DOWN	4056	RH FLOOR UP	RH FLOOR DOWN	4075
A5 EXT T5 EXT	A5 RET T5 RET	4038	LHM FLOOR UP	LHM FLOOR DOWN	4057	6,7T Friløb	Front Friløb	4076
A6 EXT T6 EXT	A6 RET T6 RET	4039	LHF FLOOR UP	LHF FLOOR DOWN	4058	P.D. ROLLER UP/DOWN	AIR STOPS	4077
B1S EXT D1 EXT	B1S RET D1 RET	4040	BED ←	BED →	4059	TILT UP	ARM UP	4078
B2 EXT D2 EXT	B2 RET D2 RET	4041	FRONT LEGS ▼	FRONT LEGS ▲	4060	TILT DOWN	ARM DOWN	4079

WINCH IN	WINCH OUT	4080	BOX UP	BOX DOWN	4099	REEL OPEN MIDDLE DRAIN	REEL CLOSE REAR DRAIN	4118
SHIFT LEFT	SHIFT RIGHT	4081	CCW	CW	4100	REEL LEFT SCAM DRAIN	REEL RIGHT	4119
FRONT JACKS UP	FRONT JACKS DOWN	4082	OPEN/ DIS.	SAW/ LG	4101	RECYCLE BUMPER IN	AUTO/ PRE BUMPER OUT	4120
LR JACK UP	RR JACK UP	4083	CLOSE/ ENGAGE	TILT UP	4102			4121
LR JACK DOWN	RR JACK DOWN	4084	START	TILT DOWN	4103			4122
HIGH SPEED	SUPER SLOW	4085	RUN	FLOAT	4104	TILT UP	TILT DOWN	4123
TABLE UP/DOWN	VIBRATION UP/DOWN	4086	CLUTCH	CLUTCH	4105	WINCH 1 IN	WINCH 1 OUT	4124
FREQUENCY UP	FREQUENCY DOWN	4087	PUMP INCR.	PUMP DECR.	4106	WINCH 2 IN	WINCH 2 OUT	4125
IMPULSE ON/OFF	BOOST ON	4088	PUMP ON	PUMP OFF	4107	LEFT WINCH IN	LEFT WINCH OUT	4126
B.D. ROLLER UP/DOWN	REAR AIR STOPS	4089	VALVE OPEN	VALVE CLOSE	4108	RIGHT WINCH IN	RIGHT WINCH OUT	4127
P.D. ROLLER UP/DOWN	FRONT AIR STOPS	4090	REEL IN		4109	SLIDE FWD	SLIDE BACK	4128
Silo 1	Silo 2	4091	VAC JETTER	VACUUM	4110	DSA EXTEND	DSA RETRACT	4129
Silo 3	Silo 4	4092	JETTER	HOSE REEL	4111	DSS EXTEND	DSS RETRACT	4130
Silo 5	Silo 6	4093	HOLD		4112	PSA EXTEND	PSA RETRACT	4131
Schieber Auf	Schieber Zu	4094	VACUUM TRANSFER PUMP	JETTING AUTO DRAIN	4113	PSS EXTEND	PSS RETRACT	4132
1 OPEN	1 CLOSE	4095	CHANGE OVER REVS UP	VENT REVS DOWN	4114	RST EXTEND	RST RETRACT	4133
2 OPEN	2 CLOSE	4096	BOOM LEFT TIP UP	BOOM RIGHT TIP DOWN	4115	LFL EXTEND	LFL RETRACT	4134
3 OPEN	3 CLOSE	4097	BOOM UP WATER FILL	BOOM DOWN BOOM VALVE	4116	RFL EXTEND	RFL RETRACT	4135
SP WINCH IN	SP WINCH OUT	4098	REEL IN LIGHTS	REEL OUT FRONT DRAIN	4117	LRL EXTEND	LRL RETRACT	4136

RRL EXTEND		RRL RETRACT	4137	STACKER TRAVEL START		STACKER TRAVEL STOP	4156	IOB III Tür 1			4175
			4138				4157			Tür Auf/Zu	4176
START		STOP	4139	MOTOR 1 START		MOTOR 1 STOP	4158	ARMS OPEN		ARMS CLOSE	4177
			4140	MOTOR 2 START		MOTOR 2 STOP	4159	FRONT LEGS UP		REAR LEGS UP	4178
 Ramps IN		 Ramps OUT	4141	THROTTLE UP DOWN			4160	FRONT LEGS DOWN		REAR LEGS DOWN	4179
			4142	DUMP DOWN		DUMP UP	4161	SHEET UNCOVER		SHEET COVER	4180
			4143	OUT R F DWN		OUT R F UP	4162	SHEET RETRACT		SHEET EXTEND	4181
			4144	OUT R RR DWN		OUT R RR UP	4163	KICK DOORS CLOSE		KICK DOORS OPEN	4182
			4145	OUT R LR DWN		OUT R LR UP	4164			Tür 1 Auf/Zu	4183
			4146	TOOL		AUX 1	4165			Tür 2 Auf/Zu	4184
		TRIPPER FWD	4147				4166				4185
		TRIPPER REV	4148				4167				4186
BLEND STOP		BLEND START	4149				4168	TILT UP		TILT DOWN	4187
LOADOUT STOP		LOADOUT START	4150				4169				4188
IMPREG PUMP STOP		IMPREG PUMP START	4151				4170	DECK WINCH		DECK WINCH	4189
GATE CLOSE		GATE OPEN	4152				4171	B.E. Leg LOWER		B.E. Leg RAISE	4190
		VIBRATOR JOG	4153	CHASSIS 		CHASSIS 	4172	 Bremsen auf		 Bremsen auf	4191
RADIAL STACKER STOP		RADIAL STACKER START	4154	IOB I Tür 1		IOB I Tür 2	4173	LICHTER SEITWÄRTS		HINTERE LICHTER	4192
TRUCK UNLOADER STOP		TRUCK UNLOADER START	4155	IOB II Tür 1		IOB II Tür 2	4174	PUMP OFF		PUMP ON	4193

		4194			4212	DRIVE FWD	DRIVE REV	4230
		4195			4213	GRAB OPEN	GRAB CLOSE	4231
		4196	DRAW BAR OUT	DRAW BAR IN	4214	GATE 1 OPEN / SHUT	GATE 7 OPEN / SHUT	4232
WORK LIGHTS ON/OFF	DRIBBLE BAR	4197			4215	GATE 2 OPEN / SHUT	GATE 8 OPEN / SHUT	4233
GATE VALVE	BEACON ON/OFF	4198			4216	GATE 3 OPEN / SHUT	GATE 9 OPEN / SHUT	4234
		4199	FRONT WINCH IN TOP WINCH UP	FRONT WINCH OUT TOP WINCH DOWN	4217	GATE 4 OPEN / SHUT	GATE 10 OPEN / SHUT	4235
		4200	BED WINCH	FRONT WINCH TOP DECK LOCK	4218	GATE 5 OPEN / SHUT	GATE 11 OPEN / SHUT	4236
RELEASE		4201	BREAK CYL-1 IN	BREAK CYL-1 OUT	4219	GATE 6 OPEN / SHUT	GATE 12 OPEN / SHUT	4237
Blend Loadout STOP	Blend START	4202	BREAK CYL-2 IN	BREAK CYL-2 OUT	4220	ALL GATES OPEN	ALL GATES CLOSE	4238
Blend DIRECT	Loadout START	4203	BRACE CYL-1 IN	BRACE CYL-1 OUT	4221	GAUGE BAR OPEN	GAUGE BAR CLOSE	4239
Flphood LOWER	Flphood RAISE	4204	REAR V DOWN	REAR V UP	4222	RXP LH WINCH IN	RXP LH WINCH OUT	4240
STOP 1	STOP 2	4205	BRACE CYL-2 IN	BRACE CYL-2 OUT	4223	RXP RH WINCH IN	RXP RH WINCH OUT	4241
ROLLCASE REVERSE	ROLLCASE FORWARD	4206			4224	BELT ON/OFF	GATE LIFT/LOWER	4242
SWEEP CHAINS	AUTO MANUAL	4207	Ramps IN	Ramps OUT	4225	GATE LOCK/UNLOCK		4243
FRONT - L 	FRONT - R 	4208	Ramps OUT	Ramps IN	4226	TARP OPEN	TARP CLOSE	4244
FRONT - L 	FRONT - R 	4209	HAND	SYSTEM OFF	4227	Head Yoke OPEN	Head Yoke CLOSE	4245
REAR - L 	REAR - R 	4210	NEXT	PREVIOUS	4228	Side Squeeze RELEASE	Side Squeeze CLOSE	4246
		4211	LIFT UP	LIFT DOWN	4229	Rear Door OPEN	Rear Door CLOSE	4247

SHEET OPEN		SHEET CLOSE	4248	E8 OPEN		E8 CLOSE	4267
AIRGATE OPEN		AIRGATE CLOSE	4249	E9 OPEN		E9 CLOSE	4268
			4250	W1 OPEN		W1 CLOSE	4269
PUMP INCR		PUMP DECR	4251	W2 OPEN		W2 CLOSE	4270
VALVE OPEN		VALVE CLOSE	4252	RUN VAC PUMP STOP		RUN JET PUMP STOP	4271
REEL IN		REEL OUT	4253	SUCK CHANGEVER BLOW		OPEN MAIN REEL VALVE CLOSE	4272
BOOM CLOCK -WISE		BOOM ANTICLOCK -WISE	4254	VAC REEL IN		INCREASE PRESSURE	4273
BOOM VALVE OPEN		BOOM VALVE CLOSE	4255	VAC REEL OUT		DECREASE PRESSURE	4274
SHEET WIDTH OPEN		SHEET WIDTH CLOSE	4256	OPEN INLET VALVE		JETTER REEL IN	4275
E1 OPEN 1M OPEN		E1 CLOSE 1M CLOSE	4257	CLOSE INLET VALVE		JETTER REEL OUT	4276
E2 OPEN 2M OPEN		E2 CLOSE 2M CLOSE	4258	RUN POWER WASHER STOP		OPEN SMALL REEL VALVE CLOSE	4277
E3 OPEN 3M OPEN		E3 CLOSE 3M CLOSE	4259	INCREASE PRESSURE		DECREASE PRESSURE	4278
E4 OPEN 4M OPEN		E4 CLOSE 4M CLOSE	4260				
E5 OPEN 5M OPEN		E5 CLOSE 5M CLOSE	4261				
E6 OPEN 6M OPEN		E6 CLOSE 6M CLOSE	4262				
E7 OPEN 7M OPEN		E7 CLOSE 7M CLOSE	4263				
I1 OPEN 8M OPEN		I1 CLOSE 8M CLOSE	4264				
I2 OPEN 9M OPEN		I2 CLOSE 9M CLOSE	4265				
I3 OPEN 10M OPEN		I3 CLOSE 10M CLOSE	4266				